

PART NUMBER	DESCRIPTION
040-00000591	TEN SPR ADJ SCR F/JU
040-00040394	B/C TENSION SPRING
040-05140582	SCREW F/JUKI
040-05141182	SCREW F/JUKI
040-05141184	SCREW F/JUKI
040-05540583	SCREW F/JUKI
040-05541421	BOB CASE BASE F/JUKI
040-05541461	FLAT B/C SPRING F/JU
040-05742221	BOB CASE(BASE) F/JKI
040-05742264	TENSION SPRING
040-05742282	NDL CL PST SCREW F/J
040-05742283	TENS SPRG ADJ SCREW
040-51242982	SCREW F/JUKI
040-51244961	FORKED SPRING F/JUKI
040-56348963	FLAT B/C TENS SPRING
040-56348963H	TENS SPRING F/JUKI
040-56349021	HOOK BASE F/JUKI
040-56349021H	HOOK BASE F/JUKI
040-56349031	HOOK GIB F/JUKI
040-56349061	SPRING F/JUKI
060400-5-12	SCREW F/BROTERH
076003-8-50	BEARING F/BROTHER
100-06104	TAKEUP SPRING F/JUKI
100-09009	TIMING BELT F/JUKI
100-10114	N/B THR GUIDE F/JUKI
100-32555	HOOK ASLY F/JUKI
100-32555-VAL	HOOK F/JUKI
100-34056	BOBBIN CASE F/JUKI
100-78954	HOOK F/JUKI LZH 1290
100-80059	BOBBIN CASE F/JUKI
100-80604	ALUM BOBBIN F/JUKI
101-00550	SLIDE PLATE F/JUKI
101-01301	JUK THREAD GUIDE B
101-01400	THREAD GUIDE F/JUKI
101-01509	THREAD GUIDE F/JUKI
101-03406	INSIDE BELT F/JUKI
101-10005-VAL	HOOK LESS CAP F/JUKI
101-10054	HOOK F/JUKI
101-10054-VAL	HOOK W/CAP F/JUKI
101-10062	HOOK LESS CAP F/JUKI
101-10062-VAL	HOOK LESS CAP F/JUKI
101-10104	HOOK(NO CAP)F/JUKI
101-10104-VAL	HOOK W/O CAP F/JUKI
101-10153	HOOK W/CAP F/JUKI
101-10153-VAL	HOOK W/CAP F/JUKI
101-10203	B/C CAP F/JUKI
101-10252	B/C CAP F/JUKI
101-10401	SPRING F/JUKI
101-10500	SCREW F/JUKI
101-10609	TEN REG SCREW F/JUKI
101-11300	ALUM BOBBIN F/JUKI

PART NUMBER	DESCRIPTION
101-11508	SPRING F/JUKI
101-11805	B/C LEVER F/JUKI
101-14106	WIPER F/JUKI
101-15400	FIXED KNIFE F/JUKI
101-15707	CLAMP SPRING F/JUKI
101-19907	CUSHION F/JUKI
101218000-VAL	HOOK F/NAKAJIMA 580L
101-24501	THR T/U SPR STUD F/J
101-25201	CONNECTION ROD F/JUK
101-26803	OIL TUBE HOLDER F/JU
101-32504	3/16 PLATE F/JUKI
101-32603	1/4" PLATE F/JUKI
101-35101	1/8" PLT F/JK LH1152
101-35309	3/16 PLATE F/JUKI
101-35507	1/4" NDL PLATE F/JKI
101-35705	5/16 PLATE F/JUKI
101-35804	3/8 NDL PLATE F/JUKI
101-35903	JUKI THROAT PLATE
101-37503	3/16" NDL PLATE F/JK
101-37602	1/4" NDL PLATE F/JUK
101-37701	5/16" NDL PLATE F/JK
101-37800	3/8"NDL PLATE F/JUKI
101-37801	7/16"NDL PLATE F/JUK
101-37909	1/2" NDL PLATE F/JKY
101-37910	9/16"NDL PLATE F/JUK
101-38006	5/8"NDL PLATE F/JUKI
101-38105	3/4"NDL PLT F/JUKI
101-38204	7/8"NDL PLATE F/JUKI
101-38303	1" NDL PLATE F/JUKI
101-38402	1-1/8"NDL PLT F/JUK
101-38501	1-1/4"NDL PLT F/JUKI
101-38600	1-3/8"NDL PLT F/JUKI
101-38709	1-1/2"NDL PLT F/JUKI
101-45001	SLIDE PLATE F/JUKI
101-45506	SLIDE PLATE F/JUKI
101-47551	3/32" NDL CLAMP
101-47650	1/8 NDL CLAMP F/JUKI
101-47759	5/32NDL CLAMP F/JUKI
101-47858	3/16" NDL CLMP ASLY
101-47957	7/32 NDL CLMP F/JUKI
101-48005	1/4" NDL CLAMP F/JUK
101-48054	1/4" NDL CLAMP F/JUK
101-48153	9/32 NDL CLMP F/JUKI
101-48252	5/16 NDL CLMP F/JUKI
101-48351	3/8 NDL CLMP F/JUKI
101-48450	7/16 NDL CLMP F/JUKI
101-48500	1/2" NDL CLAMP F/JUK
101-48559	1/2" NDL CLAMP F/JUK
101-48609	5/8 NDL CLAMP F/JUKI
101-48658	5/8 NDL CLAMP F/JUKI
101-48757	3/4 NDL CLMP F/JUKI

PART NUMBER	DESCRIPTION
101-48856	7/8 NDL CLMP F/JUKI
101-48955	1" NDL CLAMP F/JUKI
101-49052	1-1/8 NDL CLMP F/JUK
101-49151	1-1/4"NDL CLMP F/JUK
101-49250	1-3/8"NDL CLMP F/JUK
101-49359	1-1/2 NDL CLMP F/JUK
101-50258	5/32 FOOT F/JUKI
101-51850	1-1/2" FOOT F/JUKI
101-52650	5/32" FOOT F/JUKI
101-52858	7/32" FOOT F/JUKI
101-52957	1/4" FOOT F/JUKI
101-53054	9/32" FOOT F/JUKI
101-53153	5/16" FOOT F/JUKI
101-53252	3/8" FOOT F/JUKI
101-53351	7/16" FOOT F/JUKI
101-53559	5/8" FOOT F/JUKI
101-53658	3/4" FOOT F/JUKI
101-53757	7/8" FOOT F/JUKI
101-53856	1" FOOT F/JUKI
101-53955	1-1/8" FOOT F/JUKI
101-54052	1-1/4" FOOT F/JUKI
101-54151	1-3/8" FOOT F/JUKI
101-54250	1-1/2" FOOT F/JUKI
101-55059	1/4 COMP GUIDE FOOT
101-55158	5/16 COMP GUIDE FOOT
101-65504	1/4"FINE FEEDER F/JU
101-67906	1/4" FEEDER F/JUKI
101-70405	1/4"FEED DOG F/JUKI
101-72807	FEED DOG F/JUKI
101-73508	1/2" FEEDER F/JUKI
101-86054	3/16 FOOT F/JUKI
101-95154	HOOK & BASE F/JUKI
101-95154-VAL	HOOK F/JUKI
101-95204	HOOK BASE F/JUKI
101-95303	TENSION SPRING F/JUK
101-95402	TENS ADJ SCREW F/JUK
101-97655	HOOK F/JUKI
101-97655-VAL	HOOK F/JUKI
101-97705	HOOK BASKET F/JUKI
102-05201	N/B FRAME F/JUKI
102-07751	LEFT HOOK F/JUKI
102-07850	RIGHT HOOK F/JUKI
102-07868	HOOK ASY F/JUKI
102-07959	LEFT HOOK F/JUKI
102-07959-VAL	HOOK F/JUKI
102-08056	RIGHT HOOK F/JUKI
102-08056-VAL	HOOK F/JUKI
102-08254	BOBBIN CASE F/JUKI
102-08304	BC TEN SPRING F/JUKI
102-09203	THREAD WIPER F/JUKI
102-09807	THREAD WIPER F/JUKI

PART NUMBER	DESCRIPTION
102-11001	JUKI MOV KF SUP PLT
102-11100	MOVING KNIFE F/JUKI
102-11118	MOVING KNIFE F/JUKI
102-11209	COUNTER KNIFE F/JUKI
102-11308	THRD PRESSER F/JUKI
102-11605	MOVING KNIFE F/JUKI
102-20408	PLATE F/JUKI
102-20507	1/4" PLATE F/JUKI
102-22651	1/4"FOOT F/JUKI
102-27105	3/32"NDL PLATE F/JU
102-27106	1/8"NDL PLATE F/JUK
102-27205	5/32"NDL PLATE F/JUK
102-27304	7/32"NDL PLATE F/JUK
102-27403	9/32"NDL PLATE F/JUK
102-31553	BOB CASE CAP F/JUKI
102-31603	BOBBIN F/JUKI
102-31603-4	AL BOBBN 4LONG HOLES
102-32403	COUNTER KNIFE F/JUKI
102-33807	3/4"NDL PLATE F/JUKI
102-33906	1" NDL PLATE F/JUKI
102-35901	3/16 PLATE F/JUKI
102-36107	1/4" PLATE F/JUKI
102-39309	1/4" FEEDER F/JUKI
103-08609	THREAD GUARD F/JUKI
103-12403	COUNTER KNIFE F/JUKI
103-37905	FINGER GUARD F/JUKI
103-52805	B/C TEN SPRING F/JUK
103-53076	JUKI HOOK RIGHT ASSM
103-53605	BOBBIN F/JUKI
103-53605-4	ALUM BOBBIN F/JUKI
103-54009	LRG STL BOBBIN F/JUK
106-97068	LATCH HOOK ASLY F/JK
106-97084	LATCH HOOK ASM F/JK
107-01704	PLATE F/JUKI
107-01803	SLIDE PLATE F/JUKI
107-01902	SLIDE PLATE F/JUKI
107-02405	THR TAKEUP SPRG F/JU
107-08204	THREAD GUIDE F/JUKI
107-11653	INSIDE FOOT F/JUKI
107-12252	OUTSIDE FOOT F/DU-AD
107-12552	OUTSIDE FOOT F/JUKI
107-17106	FEEDER F/JUKI
107-22551	HOOK F/JUKI
107-22551-VAL	HOOK F/JUKI
107-22700	BOBBIN CASE F/JUKI
107-22809	IN HOOK PRESSER F/JU
107-22908	TENSION SPRING F/JUK
107-23104	SCREW F/JUKI
107-23302	SCREW F/JUKI
107-23401	SCREW F/JUKI
107-23500	SPRING F/JUKI

PART NUMBER	DESCRIPTION
107-23609	ALUM BOBBIN F/JUKI
107-23609S	BOBBIN F/JUKI
107-26305	MOVING KNIFE F/JUKI
107-26404	FIXED KNIFE F/JUKI
107-26909	CLAMP SPRING F/JUKI
107-53150	JUKI R SLIDE PLATE
107-59603	ALUM BOBBIN F/JUKI
107-76805	ALUM BOBBIN F/JUKI
109068030	HOOK F/NAKAJIMA
110-00619	GASKET F/JUKI
110-01500	SCREW F/ARM THRD GUD
110-01658	SLIDE PLATE F/JUKI
110024000	PLATE SPRING F/NAK
110-05006	NEEDLE BAR F/JUKI
110-06103	THREAD GUIDE F/JUKI
110-06905	CONNECTION ROD F/JUK
110-09909	FEED REG SCREW F/JU
110-10006	FEED DIAL F/JUKI
110-15609	POSITION FINGER F/JU
110-18504	ARM THR GUIDE A F/JU
110-18603	THREAD GUIDE F/JUKI
110-18801	N/B THR GUIDE F/JUKI
110-18900	TENSION NUT F/JUKI
110-18959	THR TENSION ASY F/JU
110-20005	OIL PUMP F/JUKI
110-20054	OIL PUMP ASLY F/JUKI
110-21300	OIL TUBE F/JUKI
110-23108	GASKET F/JUKI
110-23355	BELT COVER ASY F/JUK
110-23363	BELT COVER ASLY F/JK
110-23751	K/L ROD ASLY F/JUKI
110-24007	VERT ROD LIFTER F/JU
110-24106	SPRING F/JUKI
110-24205	KNEE PRESS ROD F/JU
110-24502	BRACKET (HUB) F/JUKI
110-24510	BRACKET(HUB) F/JUKI
110-24569	BRACKET (HUB) F/JUKI
110-24700	GASKET F/JUKI
110-28156	PRESSER FOOT ASSY
110-28172	PRESSER FOOT ASSY
110-35300	N/B THR GUIDE F/JUKI
110-37405	SPRING F/JUKI
110-38650	ROTARY HOOK F/JUKI
110-38650-CM	ROTARY HOOK F/JUKI
110-38650-VAL	HOOK F/JUKI
110-38759	BOBBIN CASE F/JUKI
110-38759-TOWA	NBL BOBBIN CASE
110-38759-VAL	NBL BOBBIN CASE F/JU
110-38809	POSITION FINGER F/JK
110-39062	T/U LEVER ASY F/JUKI
110-39070	TAKE UP ASLY F/JUKI

PART NUMBER	DESCRIPTION
110-40052	MOVABLE KNIFE F/JUKI
110-40201	THREAD GUIDE F/JUKI
110-40409	KNF HNG SCREW F/JUKI
110-40508	FORKED BASE F/JUKI
110-41506	RETURN SPRING F/JUKI
110-42652	THR TAKUP ASM F/JUKI
110-45002	TENSION POST F/JUKI
110-45051	TENSION UNIT F/JUKI
110-45101	TEN SPRING F/JUKI
110-45200	THRD TEN GUIDE F/JUK
110-45309	TENSION NUT F/JUKI
110-46158	TENSION UNIT F/JUKI
110-47107	RUBBER CUSHION F/JUK
110-71008	T/U GUARD COVER F/JU
110-71305	HAND WHEEL F/JUKI
110-71602	PR SPR REGULATOR F/J
110-71701	NUT F/JUKI
110-71800	HAND LIFTER F/JUKI
110-71909	STITCH DIAL F/JUKI
110-72204	TEN REG CAP F/JUKI
110-72253	THRD TENSION ASSY
110-72352	TENSION ASLY F/JUKI
110-72402	THR TENSION NUT F/JU
110-73103	PLASTIC HD RESET(PIN
110-73558	COMPLETE TENSION ASY
110-83151	BOBBIN CASE F/JUKI
110-83250	ALUM BOBBIN F/JUKI
110-91303	NEEDLE BAR F/JUKI
110-91501	THREAD GUIDE F/JUKI
110-92152	TENSION UNIT F/JUKI
110-92251	HOOK F/JUKI
110-92251-VAL	HOOK F/JUKI
110-93259	MOVING KNIFE F/JUKI
110-93606	TENSION SPRING F/JUK
110-93804	B/C POS FINGER F/JUK
110-96054	ROLLER ASLY F/JUKI
111-02209	SPRING F/JUKI
111-11309	INSTALL COLLAR F/JUK
111-11606	WIPER F/JUKI
111-41355	HOOK F/JUKI
111-41355-CM	CERLIANI HOOK F/JUKI
111-41355-VAL	VALUE-LINE HOOK
111-81559	2-SP THRS STAND F/JU
111-83159	2-SPL THREAD STAND
111-83167	2SP THR STAND F/JUKI
113-00308	THROAT PLATE F/JUKI
113-13053	MOVING KNIFE F/JUKI
113-13103	THREAD GUIDE F/JUKI
113-20108	COUNTER KNIFE F/JUKI
113-21452	HOOK F/JUKI
113-21452-VAL	HOOK F/JUKI

PART NUMBER	DESCRIPTION
113-22203	FEEDER F/JUKI
114-00801	(143169) PLATE F/JUK
114-03508	POS FINGER F/JUKI
114-09604	FIXED KNIFE F/JUKI
114-15866	SMALL BOBBIN WINDER
115-03901	GASKET F/JUKI
115-03919	GASKET F/JUKI
115063000	POS BRACKET F/NAKAJM
11512000C	BOBBIN F/NAKAJIMA
115-15152	LEVER ASSLY F/JUKI
115-15608	NDL CLAMP BASE F/JUK
115-15707	NEEDLE CLAMP F/JUKI
115-21002	JUKI FOOT SHAFT
115-21200	P/F ARM F/JUKI
115-21259	TRI HINGED TRAC FOOT
115-21507	JUKI PRESS FT HINGE
115-21903	CHAIN CUTTER F/JUKI
115-28304	MAIN FEEDER F/JUKI
115-28403	FEEDER F/JUKI
115-28502	AUX FEEDER F/JUKI
115-29005	GRAD STOPPER F/JUKI
115-29104	STOPPER WASHER F/JUK
115-39202	CHAIN LOOPER F/JUKI
115-44806	UPPER LOOPER F/JUKI
115-44905	LOWER LOOPER F/JUKI
115470005	BOBBIN CASE F/NAKAJM
115470100	SPRING F/NAKAJIMA
115-51009	THREAD GUIDE F/JUKI
115-65504	PRESSER PLATE F/JUKI
115-65603	UPPER KNF COVER F/JK
115-65801	UP KNF GD SHAFT F/JU
115-65900	CT UPPER KNIFE F/JKI
115-66502	LOWER KNIFE F/JUKI
115-66908	NDL GUARD F/JUKI
115681000	JUKI MOVEABLE KNIFE
115682000	JUKI FIXED KNIFE
115-71403	RUBBER CUSHION F/JKI
115-71502	CUSHION BASE F/JUKI
115-82103	LOOPER HOLDER F/JUKI
115-82400	UPPER LOOPER F/JUKI
115-97101	FEED DOG F/JUKI
115-98000	UPPER KNF SUP F/JUKI
116-51908	UPPER LOOPER F/JUKI
116-80402	NDL CLAMP F/JUKI
116-81301	JUKI LOOPER
116-93108	UPPER SPREADER F/JKI
117-90607	STITCH TONGUE F/JUKI
117-90706	DIFF FEED DOG F/JUKI
118-00604	OIL CAP F/JUKI
118-00802	PIN F/JUKI
118-00901	SPRING F/JUKI

PART NUMBER	DESCRIPTION
118-01008	SAFETY PLATE F/JUKI
118-01107	SAFETY PLATE F/JUKI
118-01255	CLOTH PLATE F/JUKI
118-01701	SLIDE COVER F/JUKI
118-01859	LEVER F/JUKI
118-02006	LEVER SPRING F/JUKI
118-02014	SPRING F/JUKI
118-02600	GASKET F/JUKI
118-02808	LOOPER COVER F/JUKI
118-02907	LPR COV BRACKET F/JK
118-03004	4-5/8" HINGE PIN
118-03103	JUKI COVER PLATE
118-03202	GUIDE PLATE F/JUKI
118-03301	LPR CVR PRESSER F/JK
118-03400	LPR COV PR SPR F/JUK
118-03707	CHIP GD COVER F/JUKI
118-04101	BELT COVER F/JUKI
118-05207	THREAD GUIDE F/JUKI
118-06304	RUBBER PLUG C F/JUKI
118-11205	HANDWHEEL A F/JUKI
118-15503	NDL CLAMP BASE F/JUK
118-16006	TAKE-UP LEVER F/JUKI
118-16204	NDL TH PR SPRING F/J
118-16402	PRESSER GUIDE F/JUKI
118-16501	NDL THR GUIDE F/JUKI
118-16600	TAKEUP GUIDE F/JUKI
118-16857	GUARD F/JUKI
118-16907	CLAMP F/JUKI
118-19604	PRESSER BAR F/JUKI
118-20156	PRESSER ARM F/JUKI
118-20164	PRESSER BAR F/JUKI
118-20172	PRESSER BAR F/JUKI
118-20305	LIFTING ARM F/JUKI
118-20404	PRE FT LIFT LVR F/JK
118-25205	OIL SHLD RUBBER F/JU
118-25601	RUB PLATE ASMLY F/JK
118-27607	LWR SHLD RUBBER F/JU
118-29157	LPR DR ROD ASM F/JUK
118-29314	CH LPR DR ARM F/JUKI
118-29355	UP LPR SUP ARM F/JUK
118-29363	UP LPR SUP ARM F/JUK
118-29405	CHAIN LOOPER F/JUKI
118-29504	THREAD GUIDE F/JUKI
118-29603	CH LPR THR GUIDE F/J
118-29959	ARM ASSY F/JUKI
118-31153	LPR DRV ROD ASM F/JK
118-31450	LOOPER HOLDER F/JUKI
118-31559	LOOP HOLD ASM F/JUKI
118-31617	UP LPR HOLDER F/JUKI
118-31617SC	SCREW
118-31757	PIN ASLY F/JUKI

PART NUMBER	DESCRIPTION
118-31906	FIXING PIN F/JUKI
118-32409	LOOPER SUPPORT F/JUK
118-32458	LOW LPR SUP ARM F/JU
118-32904	RT LPR THR GUIDE F/J
118-33001	LPR THR TAKEUP F/JUK
118-33100	LPR THR GUIDE F/JUKI
118-33209	TAKEUP F/JUKI
118-33308	THREAD GUIDE F/JUKI
118-33407	LOOP THRD GUIDE F/JK
118-33506	TAKEUP F/JUKI
118-33605	LPR GUIDE SUPRT F/JK
118-33613	LPR GD SUPPORT F/JU
118-40808	OIL GAUGE F/JUKI
118-41707	WORM GEAR F/JUKI
118-42606	SCREEN FILTER
118-43208	OIL FILTER F/JUKI
118-45401	UP KNF SUPPORT F/JUK
118-45500	UP KNF SUPPORT F/JUK
118-45609	CARBIDE KNIFE F/JUKI
118-45708	KNIFE F/JUKI
118-45807	CARB KNIFE F/JUKI
118-45906	UPPER CT KNIFE F/JKI
118-46003	LOWER KNIFE F/JUKI
118-46102	PRESSER PLATE F/JUKI
118-46417	ROTATING STOPPER F/J
118-47100	NDL GRD HOLDER F/JUK
118-47407	KNIFE F/JUKI
118-47506	KNIFE F/JUKI
118-47605	LWR CARB KNIFE F/JUK
118-48405	UP KNF COVER F/JUKI
118-49379	JUKI MACHINE BASE
118-49908	LOW WASTE CHUTE F/JU
118-50005	UP WASTE CHUTE F/JUK
118-50054	CHIP CHUTES COMPLETE
118-50153	CHIP CHUTE F/JUKI
118-50203	CHUTE INLET F/JUKI
118-50906	FR SUP AUX PLATE F/J
118-67108	CHIP GD COVER F/JUKI
118-67207	CHIP GUARD COVER F/J
118-67306	CHIP GUARD COVR F/JU
118-67405	CHIP GUARD COVER F/J
118-69005	NEEDLE CLAMP F/JUKI
118-69658	NEEDLE CLAMP F/JUKI
118-69955	NEEDLE CLAMP F/JUKI
118-70359	NEEDLE CLAMP F/JUKI
118-70458	"F"5mmNDL CLAMP F/JU
118-70854	NEEDLE CLAMP F/JUKI
118-72009	PR FT HINGE ARM
118-72108	PR FOOT HINGE F/JUKI
118-74609	STITCH TONGUE F/JUKI
118-74708	STITCH TONGUR F/JUKI

PART NUMBER	DESCRIPTION
118-75309	REAR PR FOOT F/JUKI
118-76158	PRESSER FOOT F/JUKI
118-76166	PRESSER FOOT F/JUKI
118-76364	PRESSER FOOT F/JUKI
118-76463	PRESSER FOOT F/JUKI
118-76851	PRESSER FOOT F/JUKI
118-76869	PRESSER FOOT F/JUKI
118-77156	PRESSER FOOT F/JUKI
118-77158	FOOT F/JUKI
118-77164	PRES FOOT ASLY F/JKI
118-77552	PRESSER FOOT F/JUKI
118-77578	PRESSER FOOT F/JUKI
118-77750	PRESSER FOOT F/JUKI
118-77768	PRESSER FOOT F/JUKI
118-78055	PRESSER FOOT F/JUKI
118-78063	PRESSER FOOT F/JUKI
118-78857	PRESSER FOOT F/JUKI
118-79657	PRESSER FOOT F/JUKI
118-79665	SHIR FOOT F/JUKI
118-80457	PRESSER FOOT F/JUKI
118-80465	SHIRRING FOOT F/JUKI
118-80564	PRESSER FOOT F/JUKI
118-81455	PRESSER FOOT F/JUKI
118-81471	PRESSER FOOT F/JUKI
118-81554	PRESSER FOOT F/JUKI
118-82107	MAIN FEEDER F/JUKI
118-82206	MAIN FEEDER F/JUKI
118-82305	MAIN FEED DOG
118-82404	MAIN FEEDER F/JUKI
118-82503	MAIN FEEDER F/JUKI
118-82800	MAIN FEED DOG F/JUKI
118-82909	MAIN FEEDER F/JUKI
118-83006	MAIN FEED DOG F/JUKI
118-83303	MAIN FEEDER F/JUKI
118-83402	MAIN FEEDER F/JUKI
118-83907	FEEDER F/JUKI
118-84004	MAIN FEEDER F/JUKI
118-84103	FEEDER F/JUKI
118-84509	MAIN FEEDER F/JUKI
118-84608	FEED DOG F/JUKI
118-84857	TENSION ASLY F/JUKI
118-85100	DIFF FEED DOG F/JUKI
118-85209	DIFF FEEDER F/JUKI
118-85308	DIFF FEEDER F/JUKI
118-85407	DIFF FEED DOG F/JUKI
118-85605	DIFF FEEDER F/JUKI
118-85803	DIFF FEEDER F/JUKI
118-85803N	FEEDER F/JUKI
118-85902	DIFF FEEDER F/JUKI
118-86009	DIFF FEEDER F/JUKI
118-86504	DIFF FEEDER F/JUKI

PART NUMBER	DESCRIPTION
118-86603	FEED DOG F/JUKI
118-87007	AUX FEEDER F/JUKI
118-87106	AUX FEEDER F/JUKI
118-87205	AUX FEEDER F/JUKI
118-87304	FEEDER F/JUKI
118-87403	AUX FEED DOG F/JUKI
118-88005	LOOPER F/JUKI
118-88104	UPPER LOOPER F/JUKI
118-88203	UPPER LOOPER F/JUKI
118-88302	UPPER LOOPER F/JUKI
118-88401	LOWER LOOPER F/JUKI
118-88501	LOOPER F/JUKI
118-88609	K86 SPREADER
118-88708	SPREADER F/JUKI
118-89904	LOWER LOOPER F/JUKI
118-90001	GUARD F/JUKI
118-90100	NEEDLE GUARD F/JUKI
118-90308	NEEDLE GUARD F/JUKI
118-90407	NEEDLE GUARD F/JUKI
118-90506	NEEDLE GUARD F/JUKI
118-90605	NEEDLE GUARD F/JUKI
118-90704	NEEDLE GUARD F/JUKI
118-96305	UP KNF SUPPORT F/JUK
118-97501	LOWER KNIFE F/JUKI
119-29700	REAR PRES FOOT F/JKI
119-30807	HINGE PIN F/JUKI
119-33850	PRESSER FOOT F/JUKI
119-33868	PRESSER FOOT F/JUKI
119-37406	JUKI FEED DOG
119-49401	COVER SPRING F/JUKI
119-49807	MAIN FEEDER F/JUKI
119-49906	DIFF FEEDER F/JUKI
119-50607	CLOTH PLATE CVR F/JK
119-50805	JUKI LOOPER COVER
119-51001	BELT COVER F/JUKI
119-56703	TENSION KNOB F/JUKI
119-56752	THR TEN ASLY(REDF)/J
119-56760	THR TENSION ASY F/JU
119-56802	BLUE TEN NUT F/JUKI
119-57859	5-SP THR STAND F/JUK
119-58600	CHIP GUARD COVER F/J
119-80604	JUKI DIFF FEEDER
119-84200	SPRING F/JUKI
119-84309	JUKI MAIN FEEDER
119-87005	AUX FEEDER F/JUKI
119-91189	PRESSER FOOT F/JUKI
119-91403	UPPER LOOPER F/JUKI
119-91908	UPPER LOOPER F/JUKI
119-95206	LOOPER F/JUKI
119-99307	LOWER LOOPER F/JUKI
119-99802	LOWER LOOPER F/JUKI

PART NUMBER	DESCRIPTION
120-00907	UP CH GD COVER F/JUK
120-03109	GUIDE SHAFT F/JUKI
120-03604	CHAIN LOOPER F/JUKI
120-04909	UPPER KNIFE F/JUKI
120-14809	UPPER SPREADER F/JUK
120-14817	UPPR SPREADER F/JUKI
120-14908	UPPER LOOPER F/JUKI
120-15301	NEEDLE GUARD F/JUKI
120-15400	NEEDLE GUARD F/JUKI
121-01309	LOOPER COVER F/JUKI
121-09104	CONNECTING ROD F/JUK
121-09153	CONNECTING ROD F/JUK
121-10219	NEEDLE HOLDER F/JUKI
121-10227	NEEDLE HOLDER F/JUKI
121-10300	BUSHING F/JUKI
121-10409	NEEDLE CLAMP F/JUKI
121-10607	NEEDLE GUIDE A F/JUK
121-10706	THR PR GUIDE F/JUKI
121-10805	PLATE SPRING F/JUKI
121-10904	PRESSER PLATE F/JUKI
121-11209	NDL THR GUIDE F/JUKI
121-11501	FOOT LFT ASMY F/JUKI
121-12009	T/U LEVER GUIDE F/JU
121-13205	SHAFT F/JUKI
121-14468	PR BAR ARM F/JUKI
121-15002	PRESS FOOT ASY F/JUK
121-15051	PRESS FOOT ASY F/JUK
121-15069	PRESS FOOT ASY F/JUK
121-15101	LIFT LEVER F/JUKI
121-15119	LIFT LEVER F/JUKI
121-19509	RUBBER F/JUKI
121-20705	LOOPER F/JUKI
121-21000	THREAD GUIDE B F/JUK
121-21109	HOOK GUIDE F/JUKI
121-21307	THR GD SPRING F/JUKI
121-22909	UP LPR HOLDER F/JUKI
121-23550	LPR SUP ARM ASM F/JU
121-32155	KNF DRIVER ASLY F/JU
121-33104	PRESSER PLATE F/JUKI
121-48607	NEEDLE CLAMP F/JUKI
121-48706	NEEDLE CLAMP F/JUKI
121-49803	NEEDLE CLAMP F/JUKI
121-50405	NEEDLE CLAMP F/JUKI
121-50603	NEEDLE CLAMP F/JUKI
121-53755	PR FOOT ASLY F/JUKI
121-53763	PR FOOT ASLY F/JUKI
121-54258	PRESSER FOOT F/JUKI
121-67508	HINGE SCREW F/JUKI
121-72805	DIFF FEEDER F/JUKI
121-76004	LOOPER F/JUKI
121-76103	UPPER LOOPER F/JUKI

PART NUMBER	DESCRIPTION
121-76202	UPPER LOOPER F/JUKI
122-20307	LOWER KNIFE F/JUKI
122-20406	LOWER KNIFE F/JUKI
122-40107	LOOPER F/JUKI
122-40602	NEEDLE GUARD F/JUKI
122-40701	NEEDLE GUARD F/JUKI
122-47102	LOOPER F/JUKI
122-47300	LOOPER F/JUKI
122-53100	NDL HOLDER BUSHING
122-53209	NEEDLE CLAMP F/JUKI
122-53803	PRESSER ARM F/JUKI
122-53811	PRESSER FOOT ARM
122-55709	SET PUMP NET F/JUKI
122-56103	WORM GEAR F/JUKI
122-80608	NEEDLE CLAMP F/JUKI
122-81309	THREAD GUIDE F/JUKI
122-81606	TAKE-UP LEVER F/JUKI
122-83503	DRIVING ARM F/JUKI
122-83800	THR GUIDE "B" F/JUKI
122-84758	TENSION ASLY F/JUKI
122-84956	TENSION ASLY F/JUKI
122-85102	TENSION ASLY F/JUKI
122-85706	TENSION ASLY F/JUKI
122-86902	CL WASTE COVER F/JU
122-87306	LOWER LOOPER ARM
123-41954	WASTE CHUTE ASSY
123-72207	JUKI TAKE-UP LEVER
123-77602	JUKI LWR KNF PRESSER
123-78808	NEEDLE CLAMP F/JUKI
123-79004	NEEDLE CLAMP F/JUKI
123-83501	LOOPER F/JUKI
123-83600	UPEER LOOPER F/JUKI
123-83808	UPPER LOOPER F/JUKI
123-84202	LOOPER F/JUKI
123-84400	CHAIN LOOPER F/JUKI
123-84509	NEEDLE HOLDER F/JUKI
123-86603	CH LPR TH GUIDE F/JU
124-47504	LOWER KNIFE F/JUKI
124-81107	UPPER LOOPER F/JUKI
124-81108	LOOPER F/JUKI
124-81800	LOWER LOOPER F/JUKI
124-82600	CHAIN LOOPER F/JUKI
128-82257	FOOT LFT ASMY F/JUKI
129-26358	1/4" NDL CLAMP F/JUK
129-40953	1/4" R LOOPER F/JUK
129-41852	1/4" L LOOPER F/JUK
131-00904	LOOPER COVER F/JUKI
131-02603	GASKET FOR JUKI
131-08600	BALL BEARING F/JUKI
131-08907	BALL BEARING F/JUKI
131-10705	NEEDLE GUIDE A F/JUK

PART NUMBER	DESCRIPTION
131-10804	NDL THRD GUIDE F/JUK
131-10903	THR PR SPRING F/JUKI
131-11000	PR PLATE A F/JUKI
131-15001	SHAFT F/JUKI
131-15407	ARM PIN F/JUKI
131-15654	PRS BAR ARM F/JUKI
131-15753	PRESS FOOT ASY F/JUK
131-16702	THRD TRIMMER F/JUKI
131-28400	THREAD GUIDE B F/JUK
131-28707	THR GD SPRING F/JUKI
131-31800	PIN F/JUKI
131-42500	OIL FILTER F/JUKI
131-42609	OIL TUBE HOLDER F/JU
131-50503	CT 118456 KNIFE F/JU
131-50602	KNIFE F/JUKI
131-50701	(118460) KNIVE F/JUK
131-50800	UP KNF GD SHAFT F/JU
131-70600	O RING F/JUKI
131-91408	AUX FEEDER F/JUKI
132-08806	NDL THR GUIDE F/JUKI
1349-SEIKO	POS SPRING F/SEIKO
1349-SEK	POS SPRING F/SEIKO
135-01200	STOPPER PLATE F/JUKI
135-03750	CLUTCH PLATE ASY F/J
135-03909	SPRING F/JUKI
135-04006	SPACER F/JUKI
135-04105	PULLEY SPRING F/JUKI
135-04204	HI SP PULLEY F/JUKI
135-04402	PULLEY F/JUKI 1850
135-04451	PULLEY ASLY F/JUKI
135-04600	SS PUL SHAFT F/JUKI
135-04709	PULLEY F/JUKI
135-05003	BALL RETAINER F/JUKI
135-08551	CYLINDER ASM F/JUKI
135-08700	PIN F/JUKI
135-15408	KNIFE DRIVE BAR F/JU
135-15556	NEEDLE PLATE F/JUKI
135-15564	NDL PLATE ASY F/JUKI
135-15606	SPRING F/JUKI
135-17206	SLD BLK STUD F/JUKI
135-17701	FEED PLATE F/JUKI
135-18006	LFT LIFT LEVER F/JUK
135-18402	TENSION SPRING F/JUK
135-18600	RT CLAMP FOOT F/JUKI
135-18709	LFT CLAMP FOOT F/JUK
135-20309	PULLEY PR PLATE F/JU
135-20804	TENSION SPRING F/JUK
135-20903	LEVER F/JUKI
135-21158	STOP MOTION ASY F/JU
135-21307	SPRING F/JUKI
135-21604	LINK F/JUKI

PART NUMBER	DESCRIPTION
135-21752	REG LEVER ASY F/JUKI
135-21760	REG LEVER ASY F/JUKI
135-22107	ROLLER SHAFT F/JUKI
135-22206	ROLLER F/JUKI
135-24004	OUTER SLEEVE F/JUKI
135-24400	SPRING F/JUKI
135-24418	SPRING F/JUKI
135-25001	SPRING F/JUKI
135-25704	SPRING F/JUKI
135-26157	BOBBIN WINDER F/JUKI
135-26405	B/W WHEEL F/JUKI
135-26504	B/W TRIP LATCH F/JUK
135-26603	B/W TRIP LATCH F/JUK
135-26702	SPRING F/JUKI
135-26900	BELL SUPPORT F/JUKI
135-33104	FINGER GUARD F/JUKI
135-42907	WORK CL FOOT RIGHT
135-48409	FEED PLATE F/JUKI
135-74009	WIPR INST PLATE F/JU
137-29058	HOOK F/JUKI
137-29058-VAL	HOOK F/JUKI
137-29066	HOOK F/JUKI
137-29066-VAL	HOOK F/JUKI
137-29769	BOBBIN CASE F/JUKI
137-63800	PULLEY RING F/JUKI
138-12102	TEF ALUM BOBBIN
143455-SEK	FORK CONNECTION F/SE
15470LB	BOB CASE F/NAKAJMA
164-16109	UPPER KNIFE F/JUKI
164-18600	UPPER KNIFE F/JUKI
164-21802	BOBBIN F/JUKI
166-07301	A1 CORNER KNIFE F/JK
166-07301-A-1	KNIFE F/JUKI
166-07400	A2 CORNER KNIFE F/JK
166-07400-A-2	A2 CORNER KNIFE F/JK
166-07707	CORNER KNIFE F/JUKI
166-07806	CORNER KNIFE F/JUKI
178-48458	BUTTON TRAY F/JUKI
182-01905	FEED PLATE F/JUKI
201143000	BOBBIN F/NAKAJIMA
205-9101-01A	KNIFE F/JUKI BABYLOK
205-9102-01A	KNIFE F/JUKI BABYLOK
210-00302	NEEDLE PLATE
210-07307	FEEDER F/JUKI
210-10251	HOOK F/JUKI
210-10251-VAL	HOOK F/JUKI
210-41850	HOOK F/JUKI
210-57401	BOBBIN F/JUKI
212-21908	THROAT PLATE F/JUKI
212-25305	FEEDER F/JUKI
213-34552	HOOK F/JUKI

PART NUMBER	DESCRIPTION
213-34552-VAL	HOOK F/JUKI
213-49709	RT SLIDE PLATE F/JUK
213-55607	THRD GDE ASLY F/JUKI
213-55656	THRD GDE ASLY F/JUKI
213-55706	JUKI THR GUIDE ASLY
213-55755	JUKI THRD GUIDE ASSM
213-78708	JUKI THR GUIDE ASLY
213-87055	HOOK F/JUKI
213-87055-VAL	HOOK F/JUKI
214-10204	FEEDER F/JUKI
214-31606	B/C CAP FOR JUKI
225-24151	BOBBIN CASE F/JUKI
225-24169	BOBBIN CASE F/JUKI
225-24201	BOBBIN F/JUKI
225-24458	HOOK F/JUKI
225-24458-VAL	HOOK F/JUKI
225-25059	HOOK F/JUKI
225-25059-VAL	HOOK F/JUKI
225-25869	HOOK F/JUKI
225-25869-VAL	HOOK F/JUKI
225-25877	HOOK F/JUKI
225-25877-VAL	HOOK F/JUKI
225-28350	TENSION DISK F/JUKI
225-96704	BOBBIN F/JUKI
226-12055-VAL	HOOK F/JUKI
226-12600	BOB CASE CAP F/JUKI
226-25008	3/32"PLATE F/LH3128
226-25107	1/8"PLATE F/LH3128
226-25206	5/32" PLATE F/JUKI
226-25305	3/16" PLATE F/JUKI
226-25404	7/32" PLATE F/JUKI
226-25503	1/4" PLATE F/JUKI
226-25602	9/32"NDL PLATE F/JUK
226-25701	5/16" PLATE F/JUKI
226-25800	3/8" PLATE F/JUKI
226-25808	1-1/2"PLATE F/LH3128
226-25909	7/16" PLATE F/JUKI
226-26006	1/2" PLATE F/JUKI
226-26105	5/8" PLATE F/JUKI
226-26204	3/4" PLATE F/JUKI
226-26303	7/8" PLATE F/JUKI
226-26402	1" PLATE F/JUKI
226-26501	1-1/8" PLATE F/JUKI
226-26600	1-1/4" PLATE F/JUKI
226-27656	1/8" FOOT F/LH3128
226-30602	1/4" FEEDER F/JUKI
226-30800	9/32" FEEDER F/JUKI
226-30909	5/16" FEEDER F/JUKI
226-31006	3/8" FEEDER F/JUKI
226-31105	7/16" FEEDER F/JUKI
226-31303	1/2" FEEDER F/JUKI

PART NUMBER	DESCRIPTION
226-31402	5/8" FEEDER F/JUKI
226-31501	3/4" FEEDER F/JUKI
226-31709	7/8" FEEDER F/JUKI
226-31808	1" FEEDER F/JUKI
226-31907	1-1/8 FEEDER F/JUKI
226-32004	1-1/4 FEEDER F/JUKI
226-35007	3/32"FEEDER F/LH3128
226-35304	3/16"FEEDER F/LH3128
226-35403	7/32"FEEDER F/LH3128
226-35502	1/4"FEEDER F/LH3128
226-35700	9/32"FEEDER F/LH3128
226-35809	5/16"FEEDER F/LH3128
226-35908	3/8"FEEDER F/LH3128
226-36005	7/16"FEEDER F/LH3128
226-36203	1/2"FEEDER F/LH3128
226-55302	COUNTER KNIFE F/JUKI
226-55401	THR PRESSER F/JUKI
226-59007	ALUM BOBBIN F/JUKI
226-88105	BOB CASE CAP F/JUKI
226-88253	HOOK ASSM F/JUKI
226-88253-VAL	HOOK F/JUKI
226-93857	HOOK COMPLETE F/JUKI
226-93857-VAL	HOOK COMPLETE F/JUKI
227-40609	SCREW F/JUKI
227-41607	THR TEN POST F/JUKI
227-49006	BOBBIN F/JUKI
227-59302	SCREW F/JUKI
228-14255	HOOK COMP F/JUKI
228-14255-VAL	HOOK COMPL F/JUKI
228-27406	B/C TEN SPRING F/JUK
229-00757	TAKE UP F/JUKI
229-01250	BED SLIDE ASM
229-01300	BED SLIDE SPRING
229-03108	COUNTER WEIGHT F/JU
229-03504	OIL SEAL F/JUKI
229-06101	NDL BAR BUSHING UPPR
229-06200	NDL BAR BUSHING LOWR
229-06309	NDL BAR THREAD GUIDE
229-06457	NDL ROD HOLDER ASM
229-07505	P/B REGULATOR F/JUKI
229-07604	NUT F/JUKI
229-07703	PR BAR GUIDE F/JJUKI
229-07802	HAND LIFTER F/JUKI
229-08305	CONNECTION ROD F/JUK
229-11903	FEED DIAL F/JUKI
229-12109	PIN SPRING F/JUKI
229-12703	REVERSE LEVER F/JUKI
229-12752	REVERSE LEVER F/JUKI
229-16407	POSITION FINGER
229-20508	ARM THREAD GUIDE A
229-20607	ARM THREAD GUIDE B

PART NUMBER	DESCRIPTION
229-20805	NDL BAR THREAD GUIDE
229-20904	TENS REL PIN F/JUKI
229-21209	TENSION POST
229-21308	TENSION NUT
229-21407	ROTATING STOPPER
229-21506	THREAD TENSION DISC
229-21605	TAKE-UP SPRING
229-21704	TENSION SPRING A
229-21803	TRD TNSON DSK PRESSR
229-23007	OIL PUMP F/JUKI
229-23056	OIL PUMP F/JUKI
229-24500	OIL TUBE F/JUKI
229-24906	SPRING F/JUKI
229-27206	HANDWHEEL F/JUKI
229-27354	SMALL WHL BOB WINDER
229-30358	2-SP THR STAND F/JKI
229-31703	UMBRELLA(LIFT ROD)
229-32453	BRACKET (HUB) F/JUKI
229-32552	THREAD GUIDE ROD ASM
229-32701	SPRING F/JUKI
229-32909	BOBBIN F/JUKI
229-32909A	ALUMINIUM BOBBIN
229-33451	BELT COVER ASY F/JUK
229-34251	KNEE LIFTER ASY F/JU
229-37056	HAND WHEEL F/JUKI
229-37064	HAND WHEEL F/JUKI
229-39508	NEEDLE BAR F/JUKI
229-42502	POS FINGER F/JUKI
229-45307	TENSION POST SOCKET
229-45455	PRE-TENSION ASY F/JU
229-45463	PRE-TENSION ASY F/JU
229-45505	TENSION SPRING F/JUK
229-45703	THR TENSION NUT F/JU
229-45802	TENSION DISC F/JUKI
229-57005	THREAD WIPER F/JUKI
229-58300	THR GUIDE PIN F/JUKI
229-62054	TENSION COMPLETE
229-65909	NEEDLE PLATE
260-00950	NIPPER ASSY F/JUKI
260-01560	LEVER ASM F/JUKI
260-03756	FINGER LEVER F/JUKI
262-00154	REG LEVER ASY F/JUKI
262-01152	BOBBIN WINDER F/JUKI
262-04909	INNER HOOK F/JUKI
262-22109	UPPER RACE SPRING
262-26209	SPRING F/JUKI
262-27900	TENSION SPRING F/JUK
270280	THREAD PULL OFF
305248	KNIFE F/BABYLOCK
305249	KNIFE F/BABYLOCK
323-830-142	FEEDER F/W&G

PART NUMBER	DESCRIPTION
400-03895	LRG NBL BOBBIN CASE
400-21791	INSIDE FOOT F/JUKI
400-22772	OUTSIDE FOOT F/JUKI
405-9101-01A	UP STL KNIFE F/BABYL
411111070	JUKI SCREW F/1156810
4507B	HOOK F/NAKAJIMA
50143403	CT UP KNIFE F/JUKI
50145403	LOWER KNIFE
546925	SINGER GASKET
55623S	DEEP SLOT BOBBIN
6030110A800	SPRING F/KINGTEX
6030131B700	CHIP GD CVR F/KINGTX
6030132B700	CHIP GD CVR F/KINGTX
6030141D700	LPR CVR PRSR F/KINGT
6030203B600	OIL CAP F/KINGTEX
6030412D700	NDL THRD PRSSR F/KNG
6030436A300	NDL BAR F/KINGTEX
6030437D100	NDL CLMP BASE F/KING
6030450D700	NDL TK UP LVR F/KING
6030452B700	TAKE UP GUIDE F/KING
6030453N700	NDL THRD PRS SPRING
6030454B700	NDL THRD PRSSR GUIDE
6030455B700	NDL THRD GUIDE F/KNG
6030462D300	NEEDLE CLAMP
6030613A100	DIF FD RCKR F/KINGTX
6030617C100	SLIDE BLOCK F/KINGTX
6030618B700	COVER FOR KINGTEX
6030710A100	LPR HLDR F/KINGTEX
6030711A100	LPR HLDR F/KINGTEX
6030714D100	LWR LOOPER SUPP ARM
6030715B700	WASHER F/KINGTEX
6030718E200	GUARD F/KINGTEX
6030720B700	LPR TAKEUP F/KINGTEX
6030725B700	LPR THRD TK UP F/KNG
6030726B700	TAKEUP FOR KINGTEX
6030734H300	LEVER GUIDE F/KINGTX
6030735A100	UP LPR LVR F/KINGTEX
6030741B700	THRD GUIDE F/KINGTEX
6030901E200	PRSR FT SHAFT F/KING
6030915D300	PRSR SPR REG F/KINGX
6030917A300	PRESSER BAR F/KINGTX
6030919B700	FT LFT LVR F/KINGTEX
6030922E100	PLUNGER F/KINGTEX
6030933B700	FT LFT LVR STP F/KNG
6031001E200	PRSR FT ARM F/KINGTX
6031002D700	THRD TRIMMER F/KINGT
6031113B700	NDL THRD GUIDE F/KNG
6031124A800	TEN SPRING F/KINGTEX
6031126D700	TENSION DISC
6031127L700	THREAD TENSION FELT
6031214E200	LWR KNF HLDR F/KINGT

PART NUMBER	DESCRIPTION
6031217B700	PRSR PLATE F/KINGTEX
6031231B700	NEEDLE GUARD HOLDER
6031232E200	NDL GUARD F/KINGTEX
6031233E200	NDL GUARD F/KINGTEX
6031301A100	KNIFE DR ARM F/KINGT
6031314C500	UPPER KNIFE
6031521G700	FILTER F/KINGTEX
6050827D100	UP LPR SUP ARM F/KIN
6050828B700	CHAIN WASHER F/KINGT
6051101B700	THRD GUIDE F/KINGTEX
6051108B700	THRD GUIDE F/KINGTEX
6051115B700	NDL THRD GUIDE F/KNG
6051134D300	TENS NUT F/KINGTEX
6051135B700	TENS DISC STOP F/KNG
6051136A800	SPRING
6051234E200	NDL GUARD F/KINGTEX
6051235E200	NDL GUARD F/KINGTEX
6051239E200	NDL GUARD F/KINGTEX
9070	BOB CASE F/NAKAJ 380
93UL883	LOOPER F/VENUS
A-1115-334-0A0	THROAT PLATE F/JUKI
A-1115-334-0B0	NDL PLATE F/MO634/D
A-1132-025-000	PLATE SET SCREW F/JU
A-1837-090-0A0	NBL BOB CASE F/JUKI
A-1837-090-0A0-TOWA	NBL BOBBIN CASE
A-1837-090-0A0-VAL	NBL BOB CASE F/JUKI
A-2512-234-000	LOOPER F/JUKI
A-2526-335-000	LOWER LOOPER F/JUKI
A-2526-335-00S	LOWER LOOPER F/JUKI
A-3125-002-000	TENSION NUT #1 F/JKI
A-3128-001-000	SPRING F/JUKI
A-3216-001-00A	JUKI RUBBER RING
A-4113-102-000	LOWER KNIFE F/JKI-LK
A-4142-335-000	CARB UP KNIFE F/JUKI
A-4145-335-000	LOWER KNIFE F/JUKI
A-9117-001-000	BOBBIN F/JUKI
A-9117-007-000	BOBBIN F/JUKI TL98
A-9117-007-000A	ALUM BOBBIN F/JUKI
AF60871	AUX FEED F/KINGTEX
AF60872	AUX FEEDER F/KINGTEX
AF60873	AUX FEEDER F/KINGTEX
AF60876	AUX FEEDER F/KINGTEX
B-1103-038-D00	1/4" PLATE F/JUKI
B-1103-380-D00	3/16 PLATE F/JUKI
B-1104-122-000	BED SCREW STUD F/JUK
B-1104-804-000	GASKET F/JUKI
B-1105-141-H00	PLATE F/JUKI
B-1105-241-H00	NEEDLE PLATE F/JUKI
B-1105-241-H00A	NEEDLE PLATE F/JUKI
B-1105-352-000	ISOLATOR F/JUKI
B-1105-804-000	SCREW/CAP F/JUKI

PART NUMBER	DESCRIPTION
B-1106-372-000	SCREW "A" F/JUKI
B-1106-372-0A0	SCREW "A" F/JUKI
B-1107-280-000	PIN F/JUKI
B-1108-019-F00	1/4" PLATE F/JUKI
B-1108-026-F00	1/4" NDL PLATE F/JUK
B-1108-026-F0B	1/4" NDL PLATE P/JUK
B-1108-372-000	COVER F/JUKI
B-1108-704-000	COVER F/JUKI
B-1109-012-000	PLATE F/JUKI
B-1109-012-00A	NEEDLE PLATE F/JUKI
B-1109-012-0A0	NEEDLE PLATE F/JUKI
B-1109-012-A00	NEEDLE PLATE F/JUKI
B-1109-012-A00-T	TEFLON NDL PLTE F/JU
B-1109-012-A0B	PLATE F/JUKI
B-1109-012-H0B	NEEDLE PLATE F/JUKI
B-1109-012-I00	NEEDLE PLATE F/JUKI
B-1109-012-I0B	THROAT PLATE F/JUKI
B-1109-027-A00	NDL PLATE F/JUKI
B-1109-027-AA0	NDL PLATE F/JUKI
B-1109-041-A00	PLATE F/JUKI
B-1109-041-C00	PLATE F/JUKI
B-1109-041-D00	PLATE F/DLN-415
B-1109-041-E00	PLATE F/JUKI
B-1109-041-F00	NEEDLE PLATE F/JUKI
B-1109-041-F0B	THROAT PLATE F/JUKI
B-1109-051-C00	5/32" PLATE F/JUKI
B-1109-051-D00	3/16" PLATE F/JUKI
B-1109-051-E00	7/32" PLATE F/JUKI
B-1109-051-F00	1/4" PLATE F/JUKI
B-1109-051-L00	1/2" PLATE F/JUKI
B-1109-051-M00	5/8" PLATE F/JUKI
B-1109-051-P00	7/8" PLATE F/JUKI
B-1109-051-Q00	1" PLATE F/JUKI
B-1109-051-S00	1-1/4" PLATE F/JUKI
B-1109-053-000	PLATE F/JUKI
B-1109-053-000A	NEEDLE PLATE F/JUKI
B-1109-057-F00	1/4" NEEDLE PLATE
B-1109-057-K00	3/8" NEEDLE PLATE
B-1109-057-L00	1/2" NEEDLE PLATE
B-1109-057-M00	5/8" NEEDLE PLATE
B-1109-057-N00	3/4" NEEDLE PLATE
B-1109-057-Q00	1" NEEDLE PLATE
B-1109-057-S00	1-1/4" NEEDLE PLATE
B-1109-057-T00	1-3/8" NEEDLE PLATE
B-1109-057-U00	1-1/2" NEEDLE PLATE
B-1109-158-FF0	1/4" GAUGE SET
B-1109-158-LF0	1/2" GAUGE SET
B-1109-158-MF0	5/8" GAUGE SET
B-1109-158-NF0	3/4" GAUGE SET
B-1109-158-QF0	1" GAUGE SET
B-1109-158-SF0	1-1/4" GAUGE SET

PART NUMBER	DESCRIPTION
B-1109-158-UF0	1-1/2" GAUGE SET
B-1109-180-000	NEEDLE PLATE F/JUKI
B-1109-180-B00	THROAT PLATE 5/64"
B-1109-180-B0A	NEEDLE PLATE F/JUKI
B-1109-372-000	STOP MOT PUL COVER
B-1109-415-A00	PLATE F/JUKI
B-1109-415-B00	PLATE F/JUKI
B-1109-415-H00	PLATE F/JUKI
B-1109-415-H0B	THROAT PLATE F/JUKI
B-1109-512-A00	3/32" PLATE F/JUKI
B-1109-512-B00A	1/8" PLATE F/JUKI
B-1109-512-C00	5/32" PLATE F/JUKI
B-1109-512-D00	3/16" PLATE F/JUKI
B-1109-512-E00	7/32" PLATE F/JUKI
B-1109-512-F00	1/4"NDL PLATE F/JUKI
B-1109-512-F0B	1/4" PLATE F/JUKI
B-1109-512-G00	9/32" PLATE F/JUKI
B-1109-512-H00	5/16" PLATE F/JUKI
B-1109-512-K00	3/8 NEEDLE PLATE
B-1109-512-L00	1/2" PLATE F/JUKI
B-1109-512-M00	5/8 PLATE F/JUKI
B-1109-512-N00	3/4" PLATE F/JUKI
B-1109-512-P00	7/8" PLATE F/JUKI
B-1109-512-Q00	1" PLATE F/JUKI
B-1109-512-R00	1-1/8" PLATE F/JUKI
B-1109-512-S00	1-1/4" PLATE F/JUKI
B-1109-512-T00	1-3/8" PLATE F/JUKI
B-1109-512-U00	1-1/2" PLATE F/JUKI
B-1109-521-D00	3/16" PLATE F/JUKI
B-1109-521-H00	5/16" PLATE F/JUKI
B-1109-521-K00	3/8" PLATE F/JUKI
B-1109-521-L00	1/2" PLATE F/JUKI
B-1109-521-M00	5/8" PLATE F/JUKI
B-1109-521-N00	3/4" PLATE F/JUKI
B-1109-521-P00	7/8" PLATE F/JUKI
B-1109-521-Q00	1" PLATE F/JUKI
B-1109-552-000	NDL PLATE F/JUKI
B-1109-553-000	NDL. PLATE F/JUKI
B-1109-555-000	NEEDLE PLATE F/JUKI
B-1109-555-H0B	NEEDLE PLATE F/JUKI
B-1109-562-000	NEEDLE PLATE F/JUKI
B-1109-562-000T	TEFLON PLATE F/JUKI
B-1109-563-000	THROAT PLATE F/JUKI
B-1109-563-C00	BINDER PLATE F/JUKI
B-1109-589-M00	NEEDLE PLATE F/JUKI
B-1110-012-0A0	SLIDE PLATE F/JUKI
B-1110-771-000	FR TP CVR GASKET F/J
B-1110-804-000	GASKET F/JUKI
B-1111-352-000	LPR CVR HNGE BRACKET
B-1111-372-000	SPRING F/JUKI
B-1111-563-000	SPRING F/JUKI

PART NUMBER	DESCRIPTION
B-1112-053-000A	SLIDE PLATE F/JUKI
B-1112-512-C00	LFT SLIDE PLATE F/JU
B-1113-053-000	SLIDE PLATE F/JUKI
B-1113-053-000A	SLIDE PLATE F/JUKI
B-1113-155-000	THR GUIDE PIN F/JUKI
B-1113-155-0A0	THRD GUIDE PIN F/JKI
B-1113-512-C00	RT SLIDE PLATE F/JUK
B-1114-012-000	SPOOL PIN F/JUKI
B-1114-051-000	SPOOL PIN F/JUKI
B-1114-057-000	SCREW F/JUKI
B-1114-280-000	SPR SUSP SCREW F/JUK
B-1114-980-000	SCREW F/JUKI
B-1115-232-000	LITE TENS SPRNG F/JK
B-1115-232-0A0	TENS CONTROLLER F/JK
B-1115-704-0A0	CLOTH PLATE STOP F/J
B-1117-552-000	RUBBER PLUG F/JUKI
B-1118-372-000	BASE SWNG COVER F/JU
B-1118-512-000	THREAD GUIDE F/JUKI
B-1118-512-000A	THREAD GUIDE F/JUKI
B-1118-512-00C	THREAD GUIDE F/JUKI
B-1119-012-A00	NEEDLE PLATE F/JUKI
B-1119-552-000	GASKET F/JUKI
B-1120-352-000	STOPPER PIN F/JUKI
B-1121-512-000	FRAME THREAD GUIDE
B-1121-716-000	GUARD COVER F/JUKI
B-1121-716-D0B	GUARD COVER F/JUKI
B-1121-816-D0B	GUARD COVER F/JUKI
B-1122-552-000	GASKET
B-1122-704-000	LOOPR CVR STP SPRING
B-1122-704-000A	LOOPER CVR STP SPR
B-1122-804-000	LPR CVR STOP SPRING
B-1123-552-000	OIL GUARD F/JUKI
B-1123-552-000A	OIL GUARD F/JUKI
B-1123-552-00A	OIL GUARD F/JUKI
B-1124-804-000	SMALL THR GUIDE F/JK
B-1125-280-000	TEN THR GUIDE F/JUKI
B-1126-201-000	THRD GD F/JUKI (HVY)
B-1126-552-000	THR GUIDE (LITE)F/JU
B-1126-553-000	THRD GD F/JUKI (HVY)
B-1127-415-000	FRAME THR GUIDE F/JU
B-1128-051-000	THREAD GUIDE F/JUKI
B-1128-372-000	SCREW "A" F/JUKI
B-1128-761-000	BELT GUARD F/JUKI
B-1129-051-000	THREAD GUIDE F/JUKI
B-1129-415-000A	FRAME THR GUIDE F/JK
B-1129-563-000	UP THR EYELET F/JUKI
B-1130-051-000	THREAD GUIDE F/JUKI
B-1130-804-000	PLATE COVER F/JUKI
B-1131-057-000	JUKI THREAD GUIDE
B-1131-512-000	THREAD GUIDE F/JUKI
B-1131-562-000	LWR FRAME GUIDE WIRE

PART NUMBER	DESCRIPTION
B-1131-804-000	HINGE PIN F/JUKI
B-1132-512-000	NUT F/JUKI
B-1132-804-000	SPRING F/JUKI
B-1134-816-000A	PLATE F/JUKI
B-1136-357-000	NEEDLE PLATE F/JUKI
B-1136-357-A00	NEEDLE PLATE F/JUKI
B-1136-357-B00	NEEDLE PLATE F/JUKI
B-1137-352-000	NEEDLE PLATE F/JUKI
B-1140-716-000	LPR CVR SPRING F/JKI
B-1140-804-000	LPR CVR SPRING F/JKI
B-1145-771-000	SD CVR GASKET F/JUKI
B-1147-555-000	STOP PIN F/JUKI
B-1148-555-000	PIN SPRING F/JUKI
B-1150-051-000	COVER PLATE F/JUKI
B-1150-563-000	JUKI TOP COVER
B-1150-804-000	THREAD GUIDE F/JUKI
B-1152-051-000	WASHER F/JUKI
B-1158-563-000	TAKE-UP LEVER COVER
B-1159-581-000	OIL PLUG F/JUKI
B-1166-552-000A	RUBBER ISOLATOR F/JK
B-1179-552-000	RUBBER PLUG F/JUKI
B-1190-522-A00	1/8" PLATE F/JUKI
B-1190-522-S00	1/8" PLATE F/JUKI
B-1190-522-T00	3/16" PLATE F/JUKI
B-1190-522-U00	1/4" PLATE F/JUKI
B-1190-522-V00	3/8" PLATE F/JUKI
B-1190-522-X00	3/32" PLATE F/JUKI
B-1191-490-000	NDL PLATE SCREW F/JU
B-1201-372-000	DRIVE SHAFT F/JUKI
B-1202-372-000	PULLEY F/JUKI
B-1203-280-000	NDL BAR CRANK F/JUKI
B-1203-372-000	DRIVING BALL F/JUKI
B-1204-372-000	PULLEY INSERT F/JUKI
B-1205-372-000	SPRING F/JUKI
B-1207-372-000	WASHER (CUP)F/JUKI
B-1208-232-000	STOP MOTION CAM F/JU
B-1208-352-000	OIL SEAL F/JUKI
B-1208-372-000	CLUTCH DISC F/JUKI
B-1208-552-000A	OIL SEAL F/JUKI
B-1208-980-000	BEARING F/JUKI
B-1208-980-00B	BEARING F/JUKI
B-1209-232-000	CAM PIN F/JUKI
B-1210-051-000	N/B CRK PIN ASM F/JK
B-1210-051-0A0	NDL BAR CRNK PIN ASY
B-1210-372-000	STOP MO DISC F/JUKI
B-1210-372-0A0	DISC F/JUKI
B-1210-980-000	SCREW F/JUKI
B-1211-232-000	STP CAM SPRING F/JKI
B-1211-372-000	PAWL F/JUKI
B-1211-804-000	BEARING F/JUKI
B-1211-980-000	THRUST BEARING F/JKI

PART NUMBER	DESCRIPTION
B-1212-372-000	PAWL (B) F/JUKI
B-1213-372-000	SCREW F/JUKI
B-1214-019-000	WHEEL RING F/JUKI
B-1214-372-000	ECCENTR WASHER F/JUK
B-1214-980-000	STOP MOTION CAM F/JK
B-1214-980-0A0	STOP MOTION CAM F/JK
B-1215-372-B00	BEARING&WASH F/JUKI
B-1215-804-000	BEARING F/JUKI
B-1215-980-000	CAM LATCH F/JUKI
B-1217-280-000	SPRING F/JUKI
B-1217-555-000	HAND WHEEL F/JUKI
B-1217-555-0A0	HAND WHEEL F/JUKI
B-1219-019-000	BELT F/JUKI
B-1219-051-000	MMAIN SHFT BRNG F/JU
B-1220-372-0A0	SHFT DR GEAR ASY F/J
B-1221-372-0A0	DR WORM GEAR ASY F/J
B-1221-771-00C	THRUST WASHER F/JUKI
B-1221-980-000	SPRING F/JUKI
B-1222-372-000	BUSHING F/JUKI
B-1222-980-000	BRAKE RING F/JUKI
B-1223-771-000	THRUST WASHER F/JUKI
B-1227-053-000	HAND WHEEL F/JUKI
B-1227-372-000	BUSHING F/JUKI
B-1227-980-000	BRAKE CAM RING F/JUK
B-1228-980-000	BEARING F/JUKI
B-1229-232-000	SNAP RING F/JUKI
B-1229-980-000	THRUST BEARING F/JKI
B-1230-372-0A0	FINGER LEVER F/JUKI
B-1231-980-000	THRUST BEARING F/JKI
B-1232-372-000	LEVER ROLL F/JUKI
B-1233-012-000	SCREW F/JUKI
B-1234-372-0A0	LPR PST FNDR CAM
B-1234-980-000	BRAKE CORK RING F/JK
B-1235-280-000	BEARING F/JUKI
B-1235-980-000	DRIVING CLUTCH F/JKI
B-1236-372-000	YOKE SLIDE F/JUKI
B-1236-373-000	YOKE SLIDE F/JUKI
B-1236-980-000	OIL SEAL F/JUKI
B-1237-280-000	BEARING F/JUKI
B-1237-372-000	FINGER F/JUKI
B-1237-373-000	YOKE SLIDE F/JUKI
B-1237-373-001	SLIDE YOKE F/JUKI
B-1237-980-000	BEARING F/JUKI
B-1239-372-000	LOOPER F/MB-372 JUKI
B-1239-373-000	LOOPER F/MB-372
B-1240-980-000	SPRING F/JUKI
B-1241-372-000	NEEDLE PLATE F/JUKI
B-1241-372-0A0	PLATE F/JUKI
B-1241-372-B00	THROAT PLATE F/JUKI
B-1241-373-000	NEEDLE PLATE F/JUKI
B-1241-373-0A0	NEEDLE PLATE F/JUKI

PART NUMBER	DESCRIPTION
B-1241-373-0B0	PLATE ASLY F/JUKI
B-1242-372-000	NEEDLE GUIDE F/JUKI
B-1242-373-000	NEEDLE GUIDE F/JUKI
B-1242-980-000	THRUST WASHER F/JUKI
B-1243-372-000	NEEDLE BEARING F/JKI
B-1243-373-000	BEARING F/JUKI
B-1243-980-000	BUSHING F/JUKI
B-1244-980-000	BEARING F/JUKI
B-1245-980-000	CLUTCH SPRING F/JUKI
B-1246-372-000	SPRING BALL F/JUKI
B-1246-980-000	DRIV PULLEY PIN F/JK
B-1247-980-000	CLUTCH F/JUKI
B-1250-980-000	DRIVING PULLEY F/JKI
B-1252-980-000	BALL RETAINER F/JUKI
B-1253-280-000	STP MOTION BALL F/JK
B-1253-980-000	STP MOTION BALL F/JK
B-1254-980-000	SPRING F/JUKI
B-1255-980-000	LARGE CLUTCH BRACKET
B-1256-980-000	CLUTCH BRACKET F/JKI
B-1301-051-000	NEOPRENE BELT F/JUKI
B-1301-158-000	TIMING BELT F/JUKI
B-1301-850-000	TIMING BELT F/JUKI
B-1303-055-A00	SPROCKET WHEEL F/JUK
B-1303-055-AA0	CLUTCH F/JUKI
B-1303-055-AA0-S	SEIKO CLUTCH F/JUKI
B-1305-055-000	SPRING F/JUKI
B-1306-155-000	TOP PINION ASY F/JUK
B-1306-155-0A0	TOP PINION ASY F/JUK
B-1306-771-0A0	TOP PINION ASY F/JUK
B-1307-055-000	LEVER F/JUKI
B-1308-055-000	LATCH F/JUKI
B-1309-055-000	LATCH SPRING F/JUKI
B-1310-055-000	LINK F/JUKI
B-1311-055-000	CLUTCH BODY F/JUKI
B-1314-055-000	PIN F/JUKI
B-1316-055-000	SCREW F/JUKI
B-1401-051-000	NEEDLE BAR F/JUKI
B-1401-053-000	NEEDLE BAR F/JUKI
B-1401-057-FAB	1/4" NDL BAR ASSY
B-1401-057-KAB	3/8" NDL BAR ASSY
B-1401-057-LAB	1/2" NDL BAR ASSY
B-1401-057-MAB	5/8" NDL BAR ASSY
B-1401-057-NAB	3/4" NDL BAR ASSY
B-1401-057-QAB	1" NDL BAR ASSY
B-1401-057-SAB	1-1/4" NDL BAR ASSY
B-1401-057-TAB	1-3/8" NDL BAR ASSY
B-1401-057-UAB	1-1/2" NDL BAR ASSY
B-1401-180-000	NEEDLE BAR F/JUKI
B-1401-271-000	NEEDLE BAR F/JUKI
B-1401-280-000	NEEDLE BAR F/JUKI
B-1401-372-000	NEEDLE BAR F/JUKI

PART NUMBER	DESCRIPTION
B-1401-372-000A	NEEDLE BAR F/JUKI
B-1401-415-A00	NEEDLE BAR F/JUKI
B-1401-450-A00	NEEDLE BAR F/JUKI
B-1401-552-A00	NEEDLE BAR F/JUKI
B-1401-552-B00	SMALL HOLE NDL BAR
B-1401-552-I00	LARGE HOLE NDL BAR
B-1401-761-000	NEEDLE BAR F/JUKI
B-1402-051-A00	3/32"NDL CLAMP F/JKI
B-1402-051-AA0	3/32"NDL CLAMP F/JKI
B-1402-051-B00	1/8" NDL CLAMP F/JKI
B-1402-051-BA0	1/8" NDL CLAMP F/JKI
B-1402-051-CA0	5/32"NDL CLAMP F/JKI
B-1402-051-D00	3/16"NDL CLAMP F/JKI
B-1402-051-DA0	3/16"NDL CLAMP F/JKI
B-1402-051-EA0	7/32"NDL CLAMP F/JKI
B-1402-051-F00	1/4" NDL CLAMP F/JKI
B-1402-051-FA0	1/4"NDL CLAMP F/JUKI
B-1402-051-GA0	9/32"NDL CLAMP F/JKI
B-1402-051-HA0	5/16"NDL CLAMP F/JKI
B-1402-051-K00	3/8 NDL CLAMP F/JUKI
B-1402-051-KA0	3/8 NDL CLAMP F/JUKI
B-1402-051-L00	1/2" NDL CLAMP F/JKI
B-1402-051-LA0	1/2" NDL CLAMP F/JKI
B-1402-051-M00	5/8" NDL CLAMP F/JKI
B-1402-051-MA0	5/8 NDL CLAMP F/JUKI
B-1402-051-N00	3/4" NDL CLAMP F/JKI
B-1402-051-NA0	3/4" NDL CLAMP F/JKI
B-1402-051-P00	7/8" NDL CLAMP F/JKI
B-1402-051-PA0	7/8" NDL CLAMP F/JKI
B-1402-051-Q00	1" NDL CLAMP F/JUKI
B-1402-051-QA0	1" NDL CLAMP F/JUKI
B-1402-051-R00	1-1/8"NDL CLAMP F/JK
B-1402-051-RA0	1-1/8"NDL CLAMP F/JK
B-1402-051-S00	1-1/4"NDL CLAMP F/JK
B-1402-051-SA0	1-1/4"NDL CLAMP F/JK
B-1402-051-T00	1-3/8"NDL CLAMP F/JK
B-1402-051-TA0	1-3/8"NDL CLAMP F/JK
B-1402-051-U00	1-1/2"NDL CLMP F/JKI
B-1402-051-UA0	1-1/2"NDL CLAMP F/JK
B-1402-352-000	UP KN ECC CAM F/JUKI
B-1402-372-000	BUSHING F/JUKI
B-1402-520-DA0	3/16" COMP NDL CLMP
B-1402-520-FA0	1/4"COMP NDL CLAMP
B-1402-520-KA0	3/8"COMP NDL CLAMP
B-1402-520-LA0	1/2"COMP NDL CLAMP
B-1402-520-MA0	5/8"COMP NDL CLAMP
B-1402-520-NA0	3/4" COMP NDL CLAMP
B-1402-521-QA0	1"COMP NDL CLAMP
B-1402-526-FALA	1/4" L NDL CL F/JUKI
B-1402-526-FARA	1/4" R NDL CL F/JUKI
B-1402-552-000A	NDL BAR BUSHING F/JK

PART NUMBER	DESCRIPTION
B-1403-155-000	NDL BAR BUSHING F/JU
B-1403-280-000	LOWER BUSHING F/JUKI
B-1403-372-000	BUSHING F/JUKI
B-1405-280-000	THREAD GUIDE F/JUKI
B-1406-019-D00	3/16" NDL CLAMP F/JU
B-1406-019-DA0	3/16" NDL CLAMP F/JU
B-1406-019-FA0	1/4" NDL CLAMP F/JUK
B-1406-026-FA0	NEEDLE CLAMP F/JUKI
B-1406-232-000	LWR N/B BUSHING F/JK
B-1406-372-000	CLMP SL BLOCK F/JUKI
B-1406-761-000	OIL FELT F/JUKI
B-1408-051-000	NDL BAR CRK ROD F/JK
B-1408-512-000	N/B CRANK ROD F/JUKI
B-1409-352-000	REAR BUSHING F/JUKI
B-1409-890-GA0	NDL CLAMP ASY F/JUKI
B-1410-526-000	BALL F/JUKI
B-1410-804-000	NDL DRV LEVER F/JUKI
B-1411-053-000	NDLE BAR CONN STUD
B-1411-053-0B0	NDL BAR CONN F/JUKI
B-1411-057-0A0	NDL BAR CLAMP ASMBLY
B-1411-481-0A0	N/B CONN LINK F/JUKI
B-1411-552-000	CONN LINK F/JUKI
B-1411-552-0A0	CONN LINK F/JUKI
B-1411-804-000	BEARING F/JUKI
B-1411-804-B00	BEARING F/JUKI
B-1412-051-000	OIL FELT/WICK F/JUKI
B-1412-372-0A0	BALL JOINT F/JUKI
B-1414-232-000	SLIDE BLOCK F/JUKI
B-1414-372-000	N/B CONN ROD F/JUKI
B-1414-372-0A0	ROD F/JUKI
B-1415-352-000	NDL CLAMP NUT F/JUKI
B-1415-357-A00	NEEDLE CLAMP F/JUKI
B-1415-357-BA0	"B" NDL CLAMP F/JUKI
B-1415-357-C00	NEEDLE CLAMP F/JUKI
B-1416-053-000	THRD REL GUIDE F/JUK
B-1416-053-00A	THRD REL GUIDE F/JUK
B-1416-053-00B	THRD REL GUIDE F/JUK
B-1416-053-0A0	THRD REL GUIDE F/JUK
B-1417-526-000	HALF RING F/JUKI
B-1417-555-000	TEN REG SPRING F/JUK
B-1418-372-000	SCREW F/JUKI
B-1418-518-000	NEEDLE BAR F/JUKI
B-1418-541-000	THREAD GUIDE F/JUKI
B-1418-552-A00	THREAD GUIDE F/JUKI
B-1418-552-B00	THREAD GUIDE F/JUKI
B-1419-053-000	NDL BAR THREAD GUIDE
B-1419-155-000	THREAD GUIDE F/JUKI
B-1419-245-000	N/B THREAD GUIDE F/J
B-1419-352-000	TAKE UP F/JUKI
B-1419-357-000	NDL BAR THRD TK-UP
B-1419-553-000	N/B THR GUIDE F/JUKI

PART NUMBER	DESCRIPTION
B-1419-704-0A0	NEEDLE CLAMP F/JUKI
B-1419-716-000	NEEDLE CLAMP F/JUKI
B-1419-716-000A	NDL CLAMP BASE F/JKI
B-1419-816-0A0	NEEDLE CLAMP F/JUKI
B-1420-053-000	NDL BAR FRAME F/JUKI
B-1420-352-000	TENSION DISC F/JUKI
B-1420-712-D00	NDL CLAMP F/JUKI
B-1420-716-000	NEEDLE CLAMP F/JUKI
B-1420-716-B00	NEEDLE CLAMP F/JUKI
B-1420-716-D00	NEEDLE CLAMP F/JUKI
B-1420-716-F00	NEEDLE CLAMP F/JUKI
B-1421-051-000	TAPER STUD F/JUKI
B-1421-155-000	N/B GUARD F/JUKI
B-1421-352-000	SCREW F/JUKI
B-1421-522-000	N/B GUARD F/JUKI
B-1422-352-000	TENS SPRING F/JUKI
B-1422-804-000	UPR LOOPER SHAFT PIN
B-1422-804-0A0	GUIDE PIN F/JUKI
B-1422-804-C00	SHAFT PIN
B-1422-804-CA0	PIN ASSEMBLY F/JUKI
B-1422-816-000	THREAD GUIDE F/JUKI
B-1423-051-000	N/B FRAME GUIDE F/JK
B-1423-352-000	NDL THRD EYELET F/JK
B-1423-704-000	NDL THR PRESSER F/JK
B-1424-804-000	TK-UP LVR TEN SPRING
B-1425-051-000	SLIDE BLOCK F/JUKI
B-1425-352-000	NDL BEARING F/JUKI
B-1425-704-000	NDL THRD TENS DISC
B-1425-816-000	NDL THRD TENSIN DISC
B-1426-804-000	NDL THRD TENSION SPR
B-1427-804-000	SCREW F/JUKI
B-1428-804-000	NDL THRD TK-UP LEVER
B-1435-804-000	NEEDLE CLAMP F/JUKI
B-1455-057-000	JUKI DRIVING LINK
B-1457-055-000	SCREW F/JUKI
B-1458-053-000	CONN LINK F/JUKI
B-1458-055-B00	WING NUT F/JUKI
B-1458-241-H00	UP FD CONN LINK F/JU
B-1459-053-000A	"L" SHAPE LINK F/JUK
B-1459-053-00A	"L" SHAPE LINK F/JKI
B-1459-053-00B	STUD F/JUKI
B-1460-053-0A0	BRACKET ASLY F/JUKI
B-1461-053-0A0	THREAD RELEASE GUIDE
B-1462-053-000	THREAD RELEAS SPRING
B-1465-053-000	DRIVING LINK F/JUKI
B-1466-053-000	WALKING BAR F/JUKI
B-1466-057-000	WALKING BAR F/JUKI
B-1467-053-000	SPR-POLE F/WALK-BAR
B-1467-053-00A	SPR-POLE F/WALK-BAR
B-1467-053-00B	ROLLER F/JUKI
B-1468-053-000	SPRING F/JUKI

PART NUMBER	DESCRIPTION
B-1469-053-000	SCREW F/JUKI
B-1470-053-000	INSIDE FOOT F/JUKI
B-1470-053-0A0	INSIDE FOOT F/JUKI
B-1470-053-C00	WALKING FOOT F/JUKI
B-1470-158-FA0	1/4" VIBR-PRES-FOOT
B-1470-158-KA0	3/8" VIBR-PRES-FOOT
B-1470-158-LA0	1/2" VIBR-PRES-FOOT
B-1470-158-MA0	5/8" VIBR-PRES-FOOT
B-1470-158-NA0	3/4" VIBR-PRES-FOOT
B-1470-158-QA0	1" VIBR-PRES-FOOT
B-1470-158-SA0	1-1/4"VIBR PRES FOOT
B-1470-158-TA0	1-3/8 IN FOOT F/JUKI
B-1470-158-UA0	1-1/2"VIBR PRES FOOT
B-1470-241-H00	INSIDE FOOT F/JUKI
B-1470-245-000	WALKING FOOT(INSIDE)
B-1470-521-DA0	3/16" IN FOOT F/JUKI
B-1470-521-FA0	1/4" IN FOOT F/JUKI
B-1470-521-KA0	3/8" IN FOOT F/JUKI
B-1470-521-LA0	1/2" IN FOOT F/JUKI
B-1470-521-NA0	3/4" IN FOOT F/JUKI
B-1470-521-QA0	1" IN FOOT F/JUKI
B-1470-562-B00	PRESSER FOOT F/JUKI
B-1471-562-000	NDL GUARD F/JUKI
B-1471-562-000A	NEEDLE GUARD F/JUKI
B-1501-040-000	PRESSER BAR F/JUKI
B-1501-051-A00	UP P/B BUSHING F/JU
B-1501-057-000	PRESSER BAR F/JUKI
B-1501-127-000	PRESSER BAR F/JUKI
B-1501-180-A00	MAT F/JUKI
B-1501-241-H00	PRESSER BAR F/JUKI
B-1501-352-000	LIFTER LEVER F/JUKI
B-1501-581-000	PRESSER BAR F/JUKI
B-1502-180-AA0	RT LONG SHOE F/JUKI
B-1502-180-CA0	SHRT RT CLMP SH F/JK
B-1502-352-000	FOOT LIFT ARM F/JUKI
B-1502-563-000	JUKI GUIDE PLATE
B-1503-051-A00	UP P/B BUSHING F/JUK
B-1503-051-B00	LIFT P/B BUSHING F/J
B-1503-180-AA0	LONG LF CLMP SH F/JK
B-1503-180-CA0	SHRT LF CLMP SH F/JK
B-1504-051-000	POS GUID LEVER F/JKI
B-1505-053-000	PLATE SPRING F/JUKI
B-1505-227-000A	PRESSER SPRING F/JUK
B-1505-804-000	PES-ARM HINGE SHAFT
B-1506-716-000	PRES FOOT ARM F/JUKI
B-1506-804-000	PRESSR FT ARM F/JUKI
B-1506-816-F0B	PRESSER FT ARM F/JUK
B-1507-019-FA0	1/4" FOOT F/JUKI
B-1507-026-FA0	PRESSER FOOT F/JUKI
B-1507-716-0A0	PRESSER FOOT F/JUKI
B-1507-804-000	PRESR FOOT ONLY F/JK

PART NUMBER	DESCRIPTION
B-1507-804-0A0	PRESSER FT ASSM F/JK
B-1507-804-0B0	PRESSER FOOT F/JUKI
B-1507-804-C00	PRES FOOT BODY F/JUK
B-1507-812-DAC	PRESS FOOT F/JUKI
B-1507-814-00P	PRESSER FOOT BODY
B-1507-816-000	PRESSER FOOT F/JUKI
B-1507-816-0A0	PRESSER FOOT ASSEMB
B-1507-816-0AB	PRESSER FOOT F/JUKI
B-1507-816-0B0	PRES FT ASSEM F/JUKI
B-1507-816-DA0	FOOT F/JUKI
B-1507-816-DAB	PRESSER FOOT ASSEMB
B-1507-816-DAF	SHIRRING FOOT F/JUKI
B-1507-816-F0D	PRESSER FOOT F/JUKI
B-1507-816-FAG	SHIR FOOT(ONLY)F/JKI
B-1507-816-FAQ	SHIRRING FOOT F/JUKI
B-1508-280-000	WRK CLMP FORK-F/JUKI
B-1508-804-000	FOOT SET SPRING F/JK
B-1508-804-00B	SPRING F/JUKI
B-1508-816-000	REAR PRESSER FOOT
B-1509-038-0A0	1/4"PRES FOOT F/JUKI
B-1509-038-DA0	3/16 FOOT F/JUKI
B-1509-038-DB0	3/16 FOOT F/JUKI
B-1509-038-F00	1/4" FOOT F/JUKI
B-1509-038-FA0	1/4"PRESSER FOOT F/J
B-1509-038-FB0	1/4"PRESSER FOOT F/J
B-1509-051-000	PRS REG THUMB SCREW
B-1509-227-000	SPR REGULATOR F/JUKI
B-1509-555-000	P/B REGULATOR F/JUKI
B-1509-804-000	STITCH TONGUE F/JUKI
B-1509-804-C00	STITCH TONGUE F/JUKI
B-1509-814-00P	STITCH TOGUE F/JUKI
B-1509-816-000	HINGE F/JUKI
B-1510-227-000	PR BAR GUIDE F/JUKI
B-1510-352-0A0	PRESSER FOOT F/JUKI
B-1510-357-A00	PRESSER FOOT F/JUKI
B-1510-357-BA0	PRESSER FOOT F/JUKI
B-1510-816-000	FOOT PIN F/JUKI
B-1511-543-BA0	PRESSER FOOT F/JUKI
B-1511-555-000	NUT F/JUKI
B-1511-804-000	CHAIN SHIELD F/JUKI
B-1511-814-000	PRESSER FOOT REAR
B-1511-816-000	SCREW F/JUKI
B-1512-051-000	FOOT HAND LIFTER F/J
B-1512-352-000	FINGER F/JUKI
B-1512-357-000	STITCH TONGUE F/JUKI
B-1512-804-000	PRESSER BAR F/JUKI
B-1512-816-000	PRES FT SPRING F/JKI
B-1513-280-000	TENSION SPRING F/JKI
B-1513-804-000	PRES BAR PIN F/JUKI
B-1513-816-000	NUT F/REAR PRES FOOT
B-1514-352-000	FOOT LEVER F/JUKI

PART NUMBER	DESCRIPTION
B-1514-816-000	SCREW F/JUKI
B-1515-051-000	PIN F/JUKI
B-1515-804-000	PRESSER SPRING F/JUK
B-1515-804-000A	PRES FT SPRING F/JKI
B-1515-804-00B	SPRING F/JUKI
B-1515-816-000	SPRING (STR) F/JUKI
B-1515-816-00B	SPRING (WAV) F/JUKI
B-1517-704-000	LIFTING BAR F/JUKI
B-1518-704-000	FOOT RELEASE LEVER
B-1518-804-000	FOOT RELEASE LEVER
B-1519-804-000	PIN F/JUKI
B-1520-552-000	HAND LIFTER F/JUKI
B-1520-552-000A	HAND LIFER F/JUKI
B-1521-552-000	SLACK THRD REGULATOR
B-1521-555-000	SCREW F/JUKI
B-1524-012-0A0	PRESSER FOOT F/JUKI
B-1524-012-0B0	PRESSER FOOT F/JUKI
B-1524-012-0BA	PRESSER FOOT F/JUKI
B-1524-012-A00	HNG FOOT F/JUKI
B-1524-041-EA0	PRESSER FOOT F/JUKI
B-1524-051-PA0	7/8" FOOT F/JUKI
B-1524-051-RA0	1-1/8" FOOT F/JUKI
B-1524-245-000	OUTSIDE FT W/TEETH
B-1524-412-0A0	HINGED FOOT F/JUKI
B-1524-412-0B0	FOOT W/FINGER GUARD
B-1524-415-BA0	PRESSER FOOT F/JUKI
B-1524-481-CA0	SLIDING FOOT F/JUKI
B-1524-481-CB0	SLID PRES FOOT F/JUK
B-1524-481-CC0	SLID PRESS FOOT F/JK
B-1524-512-AAD	3/32" FOOT F/JUKI
B-1524-512-BAD	1/8" FOOT F/JUKI
B-1524-512-CAD	5/32" FOOT F/JUKI
B-1524-512-DA0	3/16" OPEN TOE FOOT
B-1524-512-DAD	3/16" FOOT F/JUKI
B-1524-512-EAD	7/32" FOOT F/JUKI
B-1524-512-FA0	1/4" OPEN TOE FOOT
B-1524-512-FAD	1/4" FOOT F/JUKI
B-1524-512-GAD	9/32" FOOT F/JUKI
B-1524-512-HAD	5/16" FOOT F/JUKI
B-1524-512-KAD	3/8" FOOT F/JUKI
B-1524-512-LAD	1/2" FOOT F/JUKI
B-1524-512-MAD	5/8" FOOT F/JUKI
B-1524-512-NAD	3/4" FOOT F/JUKI
B-1524-512-PAD	7/8" FOOT F/JUKI
B-1524-512-QAD	1" FOOT F/JUKI
B-1524-512-RAD	1-1/8" FOOT F/JUKI
B-1524-512-SA0	1-1/4" FOOT F/JUKI
B-1524-512-SAD	1-1/4" FOOT F/JUKI
B-1524-512-TAD	1-3/8" FOOT F/JUKI
B-1524-512-UAD	1-1/2" FOOT F/JUKI
B-1524-522-NA0-A	PRESSER FOOT F/JUKI

PART NUMBER	DESCRIPTION
B-1524-522-NB0-A	FOOT W/FNG GUARD F/J
B-1524-552-0A0	PRESSER FOOT F/JUKI
B-1524-555-0B0	PRESSER FOOT F/JUKI
B-1524-582-MA0	ZIG ZAG FOOT F/JUKI
B-1525-053-000	OUTSIDE FOOT F/JUKI
B-1525-053-0A0	OUTSIDE FOOT F/JUKI
B-1525-057-F00	1/4" OUTSD FOOT F/JK
B-1525-057-K00	3/8" OUTSD FOOT F/JK
B-1525-057-L00	1/2" OUTSD FOOT F/JK
B-1525-057-M00	5/8 OUTSD FOOT F/JKI
B-1525-057-N00	3/4" OUTSD FOOT F/JK
B-1525-057-Q00	1" OUTSD FOOT F/JUKI
B-1525-057-S00	1-1/4 OUTSD FT F/JKI
B-1525-057-T00	1-3/8 OUT FOOT F/JUK
B-1525-057-U00	1-1/2" OUTSIDE FOOT
B-1525-241-H00	OUTSIDE FOOT F/JUKI
B-1525-241-HA0	FOOT W/NDL GUARD F/J
B-1525-520-FA0	1/4 OUTSIDE FT F/JUK
B-1525-520-KA0	3/8" OUT FOOT F/JUKI
B-1525-520-NA0	3/4" OUT FOOT F/JUKI
B-1525-520-SA0	1-1/4 OUT FOOT F/JUK
B-1525-521-DA0	3/16"OUT FOOT F/JUKI
B-1525-521-LA0	1/2" OUT FOOT F/JUKI
B-1525-521-SA0	1-1/4 OUT FOOT F/JUK
B-1525-804-000	SCREW F/JUKI
B-1526-804-000	LEVER SPRING F/JUKI
B-1527-804-000	FT LIFT HOOK F/JUKI
B-1528-804-000	CHAIN CUTTER F/JUKI
B-1528-804-000A	TRIMMER F/JUKI
B-1528-804-00AJ	WHITE TRIMMER F/JUKI
B-1529-804-000	STOPPER F/JUKI
B-1530-352-000	THREAD TRIMMER F/JKI
B-1530-804-000	STOPPER F/JUKI
B-1530-816-D00	FOOT GUIDE F/JUKI
B-1534-804-000	ARM PIN F/JUKI
B-1552-816-FA0	PRESSER FOOT F/JUKI
B-1552-816-FB0	PRESSER FOOT F/JUKI
B-1602-055-000	FEED BAR F/JUKI
B-1602-352-0A0	FD ECC REG ASLY F/JK
B-1602-562-0A0	FEED BAR F/JUKI
B-1604-019-FA0	1/4" FEEDER F/JUKI
B-1604-026-A00	FEEDER F/JUKI
B-1604-051-000	FEED BAR SLIDE FORK
B-1609-041-A00	FEED DOG F/JUKI
B-1609-041-C00	FEEDER F/JUKI
B-1609-041-E00	FEED DOG F/JUKI
B-1609-041-F00	FEED DOG F/DLN415
B-1609-415-B00	FEED DOG F/JUKI
B-1609-415-H00	FEEDER F/JUKI
B-1609-804-000	NDL BEARING F/JUKI
B-1609-804-B00	BUSHING F/JUKI

PART NUMBER	DESCRIPTION
B-1610-512-000	SLIDE BLOCK F/JUKI
B-1611-055-000	SCREW F/JUKI
B-1611-562-000	CRANK CONECTION ROD
B-1613-012-000	FEEDER F/JUKI
B-1613-012-A00	FEEDER F/JUKI
B-1613-012-AOO-T	TEFLON FEEDER
B-1613-012-I00	FEEDER F/JUKI
B-1613-012-I00T	TEFLON FD DOG F/JUKI
B-1613-051-C00	5/32" FEEDER F/JUKI
B-1613-051-E00	7/32" FEEDER F/JUKI
B-1613-051-F00	1/4" FEEDER F/JUKI
B-1613-051-L00	1/2" FEEDER F/JUKI
B-1613-051-M00	5/8" FEEDER F/JUKI
B-1613-051-P00	7/8" FEEDER F/JUKI
B-1613-051-Q00	1" FEEDER F/JUKI
B-1613-051-S00	1-1/4" FEEDER F/JUKI
B-1613-051-T00	1-3/8" FEEDER F/JUKI
B-1613-053-000	FEED DOG F/LU562
B-1613-057-L00	1/2" FEEDER
B-1613-057-M00	5/8" FEEDER
B-1613-057-Q00	1" FEEDER
B-1613-057-S00	1-1/4" FEEDER
B-1613-057-T00	1-3/8" FEEDER
B-1613-057-U00	1-1/2" FEEDER
B-1613-241-H00	FEEDER F/JUKI
B-1613-352-000	FEEDER F/JUKI
B-1613-380-D00	3/16 FEEDER F/JUKI
B-1613-380-F00	1/4" FEEDER F/JUKI
B-1613-481-F00	FEEDER F/JUKI
B-1613-512-A00	3/32" FEEDER F/JUKI
B-1613-512-B00	1/8" FEEDER F/JUKI
B-1613-512-B0B	1/8" FEEDER F/JUKI
B-1613-512-C00	5/32" FEEDER F/JUKI
B-1613-512-D00	3/16" FEEDER F/JUKI
B-1613-512-D0B	3/16 FEEDER F/JUKI
B-1613-512-E00	7/32" FEEDER F/JUKI
B-1613-512-F00	1/4" FEEDER F/JUKI
B-1613-512-F0B	1/4" FEEDER F/JUKI
B-1613-512-G00	9/32" FEEDER F/JUKI
B-1613-512-H00	5/16" FEEDER F/JUKI
B-1613-512-K00	3/8" FEEDER F/JUKI
B-1613-512-K0H	3/8" FEED DOG F/JUKI
B-1613-512-L00	1/2" FEEDER F/JUKI
B-1613-512-M00	5/8" FEEDER F/JUKI
B-1613-512-N00	3/4" FEEDER F/JUKI
B-1613-512-P00	7/8 FEEDER F/JUKI
B-1613-512-P0H	7/8 FEED DOG F/JUKI
B-1613-512-Q00	1" FEEDER F/JUKI
B-1613-512-R00	1-1/8" FEEDER F/JUKI
B-1613-512-S00	1-1/4" FEEDER F/JUKI
B-1613-512-T00	1-3/8" FEEDER F/JUKI

PART NUMBER	DESCRIPTION
B-1613-512-U00	1-1/2" FEEDER F/JUKI
B-1613-521-D0A	3/16" FEEDER F/JUKI
B-1613-521-F0A	1/4"FEED DOG F/JUKI
B-1613-521-H0A	5/16" FEEDER F/JUKI
B-1613-521-K0A	3/8" FEEDER F/JUKI
B-1613-521-L0A	1/2" FEEDER F/JUKI
B-1613-521-M0A	5/8" FEEDER F/JUKI
B-1613-521-N0A	3/4" FEEDER F/JUKI
B-1613-521-P0A	7/8" FEEDER F/JUKI
B-1613-521-POA	7/8" FEEDER F/JUKI
B-1613-521-Q0A	1" FEEDER F/JUKI
B-1613-522-N00	3/16 FEEDER F/JUKI
B-1613-522-N00-A	FEEDER F/JUKI
B-1613-522-W00	FEEDER 1/4" F/JUKI
B-1613-552-000	FEEDER F/JUKI
B-1613-552-H00	FEED DOG F/JUKI
B-1613-555-H00	FEEDER F/JUKI
B-1613-555-H0B	FEEDER F/JUKI
B-1613-563-000	FEED DOG F/LU563
B-1613-563-000T	TEFLON FD DOG F/JUKI
B-1613-563-B00	FEED DOG F/JUKI
B-1613-582-M00	FEEDER F/JUKI
B-1613-582-M00T	TEFLON FEED DOG
B-1614-357-000	FEEDER F/JUKI
B-1614-357-A00	FEED DOG F/JUKI
B-1614-562-000	CRANK CONN ROD F/JUK
B-1614-562-0B0	CRANK CONN ROD ASLY
B-1614-704-000	JUKI
B-1615-357-00A	FEEDER F/JUKI
B-1619-155-000	RATCHET GEAR F/JUKI
B-1620-161-0A0	FEED REGULATOR COMPL
B-1622-057-000	FEED ECCENT GIB F/JU
B-1623-051-000	RATCHET PAWL F/JUKI
B-1623-555-0A0A	STITCH DIAL ASSEMBLY
B-1624-555-000	REVERS FEED LEVER
B-1624-555-00A	REV LEVER F/JUKI
B-1627-562-000	NDL BEARING F/JUKI
B-1630-555-000	ROCK ARM CONN F/JUKI
B-1633-555-000	PIN F/JUKI
B-1638-051-000	SNAP RING F/JUKI
B-1639-051-000	SPRING F/JUKI
B-1642-057-000	SCREW F/JUKI
B-1643-057-000	SCREW F/JUKI
B-1646-555-000	TENS SPRING F/JUKI
B-1646-704-000	SCREW F/JUKI
B-1646-704-000A	SCREW F/JUKI
B-1647-704-000A	THUMB NUT F/JUKI
B-1654-562-000	FEED CHANGE ARM F/JU
B-1654-562-0A0	FEED CHANGE ARM F/JU
B-1656-804-000	FEED DOG F/JUKI
B-1656-805-000	FEED DOG F/JUKI

PART NUMBER	DESCRIPTION
B-1656-812-D0C	MAIN FEED DOG F/JUKI
B-1656-816-000	MAIN FEED DOG F/JUKI
B-1656-816-F0DA	G816FDA FEEDER F/JUK
B-1656-816-F0H	MAIN FEED DOG F/JUKI
B-1657-804-00F	DIFF FEEDER F/JUKI
B-1657-804-00T	DIFF FEED DOG F/JUKI
B-1657-805-000-A	FEEDER F/JUKI
B-1657-805-000A	FEED DOG F/JUKI
B-1657-812-D0A	DIFF FEEDER F/JUKI
B-1657-814-B0E	DIFF FEEDER F/JUKI
B-1657-814-B0L	DIFFERENTIAL FEEDER
B-1657-816-000	DIFFER FEEDER F/JUKI
B-1657-816-D0G	DIFFER FEEDER F/JUK
B-1657-816-D0J	DIFF FEEDER F/JUKI
B-1657-816-F0FA	DIFF. FEEDER F/JUKI
B-1657-816-F0K	FEEDER F/JUKI
B-1658-804-000	AUX FEED DOG F/JUKI
B-1658-812-00A	AUX FEEDER F/JUKI
B-1660-512-B00	CRANC CON NDL BEAR
B-1663-804-000	SLIDE BLOCK F/JUKI
B-1664-562-000	NDL BEARING F/JUKI
B-1664-804-000	SPRING F/JUKI
B-1666-562-000	TENSION SPRING F/JUK
B-1805-205-000	ALUM BOBBIN F/JUKI
B-1805-210-000	ALUMINUM BOBBIN
B-1805-210-A00	ALUM BOBBIN F/JUKI
B-1806-210-D00	BOBBIN F/JUKI
B-1808-205-000	NBL SPRING F/JUKI
B-1808-552-0A0	OIL WICK ASLY F/JUKI
B-1808-552-0B0	OIL WICK ASLY F/JUKI
B-1808-761-0A0	HOOK F/JUKI
B-1808-761-0A0-CM	CERLIANI HOOK
B-1808-761-0AB	HOOK F/JUKI
B-1808-771-0A0	HOOK COMPLETE F/JUKI
B-1808-771-0A0-VAL	HOOK F/JUKI
B-1808-771-0AB	HOOK F/JUKI
B-1808-771-0AB-VAL	HOOK F/JUKI
B-1808-771-0AC	HOOK F/JUKI
B-1808-771-0AC-VAL	HOOK F/JUKI
B-1809-552-000	OIL WICK F/JUKI
B-1809-552-0A0	OIL WICK F/JUKI
B-1809-761-000	ALUM BOBBIN F/JUKI
B-1809-771-000	ALUM BOBBIN F/JUKI
B-1810-552-000	OIL WICK F/JUKI
B-1810-761-000	BOBBIN CASE F/JUKI
B-1810-761-0A0	BOBBIN CASE F/JUKI
B-1810-761-0BA	BOBBIN CASE F/JUKI
B-1810-761-B00	LATCH COMPLETE F/JUK
B-1810-761-C00	LATCH COMPLETE F/JUK
B-1810-761-E00	B/C TENS SPRING F/JU
B-1810-761-F00	LATCH SPRING F/JUKI

PART NUMBER	DESCRIPTION
B-1810-761-G00	LATCH SCREW F/JUKI
B-1810-761-G00-A	LATCH SCREW F/JUKI
B-1810-761-H00	SPR HOLD SCREW F/JUK
B-1810-761-J00	SPR ADJ SCREW F/JUKI
B-1810-771-0A0	BOBBIN CASE F/JUKI
B-1810-771-0AB	BOBBIN CASE F/JUKI
B-1810-771-0BA	BOBBIN CASE F/JUKI
B-1811-771-001	
B-1812-232-000	RACE RING F/JUKI
B-1812-280-0A0	SHUTTLE DRIVER F/JUK
B-1812-980-000	SHUTTLE DRIVER F/JUK
B-1812-980-0A0	SHUTTLE DRV ASSEMBLY
B-1813-232-000	RACE RING F/JUKI
B-1814-512-0A0	LUB SHAFT GEAR F/JUK
B-1814-563-000	HK DRV UPPER BUSHING
B-1814-761-000	NBL SPRING F/JUKI
B-1814-980-000	SHUTTLE RACE F/JUKI
B-1815-280-000	RACE SPRING F/JUKI
B-1815-563-000	HK DRV LOWER BUSHING
B-1815-980-000	RACE SPRING F/JUKI
B-1816-051-000	HOOK GEAR F/JUKI
B-1816-051-0A0	GEAR F/JUKI
B-1816-055-0A0	GEAR F/JUKI
B-1816-057-0A0	HOOK SHAFT GEAR F/JU
B-1816-232-000	RACE SPRING F/JUKI
B-1816-512-000	GEAR F/JUKI
B-1816-512-0A0	GEAR F/JUKI
B-1816-521-0A0	LRG HK SHFT GEAR F/J
B-1817-051-000	HOOK GEAR ASY F/JUKI
B-1817-053-0A0	GEAR F/JUKI
B-1817-280-000	RACE COMPLETE F/JUKI
B-1817-280-0A0	RACE COMPLETE F/JUKI
B-1817-512-000	GEAR F/JUKI
B-1817-512-0A0	GEAR ASSY F/JUKI
B-1817-515-000	GEAR F/JUKI
B-1818-051-B00	WASHER F/JUKI
B-1818-205-000	SHUTTLE HOOK F/JUKI
B-1818-210-D0B	SHUTTLE HOOK F/JUKI
B-1818-210-D0B-VAL	SHUTTLE HOOK F/JUKI
B-1818-280-000	SHUTTLE HOOK F/JUKI
B-1818-280-000HC	HARD CHR HOOK F/JUKI
B-1820-051-000	B.C.OPENER LVR LINK
B-1820-057-000	B.C.OPENER LVR LINK
B-1820-280-000	RIGHT LATCH F/JUKI
B-1820-280-000-S	TEFLON BOBBIN
B-1821-051-000	BC CRNK SC STUD F/JU
B-1821-051-0A0	BOB CRANK SCREW STUD
B-1821-232-000	COVER SPRING F/JUKI
B-1822-051-000	LEVER CRANK F/JUKI
B-1822-280-000	LATCH SHAFT F/JUKI
B-1822-512-000	B.C.OPENER LVR BASE

PART NUMBER	DESCRIPTION
B-1822-563-000	BC OPEN LVR CRNK F/J
B-1823-051-000	B.C.OPENER LVR PIN
B-1823-051-0A0	B.C.OPENER LVR PIN
B-1823-232-000	SHUTTLE HOOK F/JUKI
B-1823-280-000	SPRING F/JUKI
B-1823-512-000	B.C.OPENER LVR STUD
B-1824-051-000	B/C OPENER F/JUKI
B-1824-057-000	B/C OPENER F/JUKI
B-1824-232-0A0	COVER ASSLY F/JUKI
B-1824-512-000	B.C. OPENER LEVER
B-1824-512-000A	B/C OPENER F/JUKI
B-1824-563-000	B/C OPENER LEVER
B-1826-280-000	SPRING F/JUKI
B-1826-512-000	HK SHAFT NDL BEARING
B-1827-280-000	ALUM BOBBIN F/JUKI
B-1827-280-000-S	TEF-ALUM BOBBINS
B-1828-205-000	BOBBIN CASE F/JUKI
B-1828-205-0A0	BOBBIN CASE F/JUKI
B-1828-210-0A0	NBL BOB CASE F/JUKI
B-1828-280-00C	TENSION SPRING F/JKI
B-1828-280-0A0	BOBBIN CASE F/JUKI
B-1828-980-0A0	BOBBIN CASE F/JUKI
B-1828-980-0AB	NBL BOB CASE F/JUKI
B-1828-980-0BB	NBL BOB CASE F/JUKI
B-1830-027-0A0	HOOK COMPL F/JUKI
B-1830-027-0A0-VAL	HOOK
B-1830-041-0A0	HOOK F/JUKI
B-1830-051-0A0	HOOK F/JUKI
B-1830-051-0A0-VAL	HOOK
B-1830-055-0A0	HOOK F/JUKI
B-1830-055-0A0-CM	CERLIANI HOOK F/JUKI
B-1830-055-0A0-VAL	HOOK F/JUKI
B-1830-057-0A0	HOOK F/JUKI
B-1830-057-0A0-VAL	HOOK F/JUKI
B-1830-057-SA0	HARD PT HOOK F/JUKI
B-1830-059-0A0	HOOK F/CONSEW
B-1830-059-0A0-VAL	HOOK F/JUKI
B-1830-127-0A0	HOOK F/JUKI
B-1830-127-0A0-CM	CERLIANI HOOK F/JUKI
B-1830-127-HA0-CM	CERLIANI HOOK
B-1830-127-HA0-VAL	HOOK F/JUKI
B-1830-141-HA0	HOOK F/JUKI
B-1830-141-HA0-VAL	HOOK F/JUKI
B-1830-201-0A0	HOOK F/JUKI
B-1830-201-0A0-VAL	HOOK F/JUKI
B-1830-201-HA0	HOOK F/JUKI
B-1830-201-HA0-VAL	HOOK F/JUKI
B-1830-241-HA0	HOOK F/JUKI
B-1830-241-HA0-VAL	HOOK F/JUKI
B-1830-405-0A0	ROTATING HOOK F/JUKI
B-1830-415-0A0	HOOK F/JUKI DLN415

PART NUMBER	DESCRIPTION
B-1830-415-0A0-CM	CERLIANI HOOK F/JUKI
B-1830-415-0A0-VAL	HOOK F/JUKI
B-1830-512-0A0	HOOK F/JUKI
B-1830-512-0A0-CM	CERLIANI HOOK
B-1830-512-0A0-VAL	VALUE-LINE HOOK
B-1830-512-0AH	HOOK F/JUKI
B-1830-512-0AH-VAL	HOOK F/JUKI
B-1830-521-0A0	HOOK ONLY F/LUH526
B-1830-521-0A0-VAL	HOOK W/O CAP F/JUKI
B-1830-521-HA0	HOOK F/JUKI
B-1830-521-HA0-VAL	HOOK F/JUKI
B-1830-526-0B0	HOOK W/CAP F/LUH526
B-1830-526-0B0-VAL	HOOK W/CAP F/JUKI
B-1830-555-BAG	HOOK F/JUKI
B-1830-555-GA0	HOOK F/JUKI
B-1830-555-GA0-CM	HOOK F/JUKI
B-1830-555-GA0-VAL	HOOK F/JUKI
B-1830-555-GAO-CM	HOOK F/JUKI
B-1830-555-HA0	HOOK F/JUKI
B-1830-555-HA0-CM	CERLIANI HOOK
B-1830-555-HA0-VAL	HOOK F/JUKI
B-1830-563-0A0	HOOK F/JUKI-LU563
B-1830-563-0A0-CM	HOOK F/JUKI
B-1830-563-0A0-VAL	HOOK F/JUKI
B-1830-563-BA0	HOOK F/JUKI
B-1830-563-BA0-CM	CERLIANI HOOK
B-1830-563-BA0-VAL	HOOK F/JUKI
B-1830-581-0A0	HOOK F/JUKI
B-1830-710-0A0	ROTATING HOOK F/JUKI
B-1830-980-0A0	BOBBIN CASE F/JUKI
B-1831-055-000	SCREW F/JUKI
B-1835-012-000	POSITION FNGR F/JUKI
B-1835-141-E00	POS FINGER F/JUKI
B-1835-201-000	B/C POSITION FINGER
B-1835-241-H00	B/C POSITION FINGER
B-1836-232-0A0	BOBBIN CASE F/JUKI
B-1837-012-0A0	BOBBIN CASE F/JUKI
B-1837-027-0A0	BOBBIN CASE F/LZ271
B-1837-027-0A0-TOWA	BOBBIN CASE F/JUKI
B-1837-041-0A0	BOBBIN CASE F/DLN415
B-1837-201-0A0	BOBBIN CASE F/JUKI
B-1837-201-HA0	BOBBIN CASE F/JUKI
B-1837-201-SA0	NBL BOB CASE F/JUKI
B-1837-241-H00	BOBBIN CASE F/JUKI
B-1837-241-H00-VAL	VALUE-LINE BOBB CASE
B-1837-241-H0B	BOB CASE TEN SPRING
B-1837-241-H0C	BOB CASE TEN SPRING
B-1837-241-S00	BOBBIN CASE F/JUKI
B-1837-521-00B	B/C SPRING F/JUKI
B-1837-521-0A0	BOB CASE CAP F/JUKI
B-1837-526-00B	TEN SPRING F/JUKI

PART NUMBER	DESCRIPTION
B-1837-526-00C	AUX CHK SPRING F/JUK
B-1837-526-0A0	BOB CASE CAP F/JUKI
B-1837-528-00C	B/C SPRING F/JUKI
B-1837-528-0A0	BOB CASE CAP F/JUKI
B-1837-555-BA0	NBL BOB CASE F/JUKI
B-1837-555-BAA	NBL BOB CASE F/JUKI
B-1837-582-0A0	BOBBIN CASE F/JUKI
B-1837-586-0A0	BOBBIN CASE F/JUKI
B-1839-563-000	OIL COVER F/JUKI
B-1840-051-000	HK SH FD CAM F/JUKI
B-1840-051-0A0	FEED LIFTNG CAM F/JK
B-1841-563-000	OIL DRIP FELT F/JUKI
B-1853-141-E00	POS FINGER F/JUKI
B-1853-512-00B	HOOK SHAFT WASHER
B-1853-512-00BA	HK SHFT WASHER F/JK
B-1901-232-0A0	TAKE UP F/JUKI
B-1901-280-0A0	THRD TK-UP LEVER
B-1901-512-0A0	THRD TK-UP LVR ASSEM
B-1901-552-0A0	THRD TK-UP LVR ASSMB
B-1901-552-0C0	TAKE UP F/JUKI
B-1903-541-000	END SCREW F/JUKI
B-1903-552-000	SCREW F/JUKI
B-1904-280-000	LEVER PIN F/JUKI
B-1904-541-000	THRD TK-UP LVR PIN
B-1905-053-000	THREAD TK-UP LEVER
B-1905-053-0A0	THRD TK-UP LEVER ASM
B-1905-057-000	TAKE UP F/JUKI
B-1905-541-B00	THREAD NDLE BEARING
B-1905-563-000	THREAD TK-UP LEVER
B-1905-563-0A0	THRD TK-UP LVR ASSEM
B-1905-563-0B0	TAKE UP LVR ASY F/JU
B-1906-051-000	TK-UP LEVER PIN
B-1906-051-0A0	TAKE UP LVR PIN F/JU
B-1907-051-000	TK-UP LVR THRUST PIN
B-1910-552-000	WASHER F/JUKI
B-2001-761-000	NDL THRD TRIM ASSEMB
B-2001-761-0A0	THRD TRIMMER ASSY
B-2001-762-000	LOW THR TRIMMER F/JU
B-2001-762-0A0	THRD TRIMMER F/JUKI
B-2001-763-0A0	NDL THR TRIMMER F/JK
B-2001-771-000	LWR THRD TRIM BLADE
B-2001-771-0A0	NDL THRD TRIMMER COM
B-2002-761-0A0	UPR THRD TRIM BLADE
B-2002-771-000	BLADE(UPER) F/JUKI
B-2002-771-0A0	UP THR TR BLADE F/JU
B-2003-761-000	NDL THRD TEN SPRING
B-2003-771-000	NDL THRD PRES SPRING
B-2006-372-000	SCREW F/JUKI
B-2007-232-000	TENSION SPRING F/JUK
B-2008-038-B00A	1/8" LOOPER F/JUKI
B-2008-038-D00	3/16" LOOPER F/JUKI

PART NUMBER	DESCRIPTION
B-2008-038-F00	1/4 FR LOOPER F/JUKI
B-2008-038-F00A	1/4 FR LOOPER F/JUKI
B-2009-038-B00	1/8" LOOPER F/JUKI
B-2009-038-D00	3/16 LOOPER F/JUKI
B-2009-372-000	TEN REL LEVER F/JUKI
B-2010-372-000	REAR BLOCK F/JUKI
B-2011-357-000	CHAIN LOOPER F/JUKI
B-2011-372-000	NIP BAR BLOCK F/JUKI
B-2014-372-000	THREAD GUIDE F/JUKI
B-2015-372-000	THREAD TENSION STUD
B-2015-372-0A0	THRD TENS ASM F/JUKI
B-2017-372-000	SPRING F/JUKI
B-2018-232-000	THREAD NIPPER
B-2019-372-000	TENSION POST #2 F/JU
B-2019-372-0A0	TENSION UNIT F/JUKI
B-2019-372-0AA	TENSION UNIT F/JUKI
B-2020-372-000	RELEASE PIN F/JUKI
B-2025-372-000	LEVER ASLY F/JUKI
B-2025-372-0A0	THR PULL OFF F/JUKI
B-2025-372-0B0	LEVER F/JUKI
B-2028-372-000	NIPPER BLOCK F/JUKI
B-2029-372-000	SPRING F/JUKI
B-2030-380-000	LEFT LOOPER F/JUKI
B-2030-481-000	LOOPER F/JUKI
B-2031-372-0A0	NIPPER ASSEMBLY
B-2034-372-000	SCREW STUD F/JUKI
B-2035-372-000	NUT F/JUKI
B-2036-372-000	STUD F/JUKI
B-2037-372-000	SPRING F/JUKI
B-2038-372-000	THREAD GUIDE F/JUKI
B-2040-373-000	THREAD GUIDE F/JUKI
B-2101-232-000	THREAD WIPER WIRE
B-2101-280-0A0	WIPER F/LK-280 JUKI
B-2103-816-0A0	ARM ASY F/JUKI
B-2104-357-000	BLOCK F/JUKI
B-2104-816-000	STUD F/JUKI
B-2105-357-000	FRONT BUSHING F/JUKI
B-2106-357-000	STR & REV FEED F/JKI
B-2110-280-000	SPRING F/JUKI
B-2118-816-000	LOOPER F/JUKI
B-2120-816-000	CHAIN PIN F/JUKI
B-2201-357-000	BOB THRD CAM F/JUKI
B-2201-816-000	THREAD CAM F/JUKI
B-2203-816-000	THREAD GUIDE F/JUKI
B-2204-357-000	SPRING F/JUKI
B-2204-816-000	THREAD CAM HOOK
B-2205-357-000	LWR THR GUIDE F/JUKI
B-2212-481-000	JUKI LP THD GUD (R)
B-2218-481-000	CAST OFF WIRE F/JUKI
B-2219-232-000	SNAP RING F/JUKI
B-2219-581-000	SNAP RING F/JUKI

PART NUMBER	DESCRIPTION
B-2302-280-000	TENSION POST F/JUKI
B-2302-280-0A0	TENSION CONTROLER
B-2303-280-000	TENS REL PIN F/JUKI
B-2304-980-000	RELEASE LINK TR F/JK
B-2307-019-000	TENSION POST F/JUKI
B-2307-019-0A0	TEN POST ASY F/JUKI
B-2311-380-B00	REAR NDL GUARD F/JUK
B-2311-380-E00	MOV NDL GUARD F/JUKI
B-2313-180-000	TENSION DISC
B-2313-280-000	TENSION BARREL F/JUK
B-2314-019-000	TENSION NUT F/JUKI
B-2401-027-0B0	KNEE LIFTER F/JUKI
B-2401-372-0A0	SHANK BUTTON CLAMP
B-2401-372-0B0	SHANK BUTTON CLAMP
B-2401-372-LA0	SHNK BUT CLAMP F/JKI
B-2401-771-0A0	NDLE PLATE BASE ASSM
B-2401-980-0A0	ROD TRIP ASLY F/JUKI
B-2402-027-000	KNEE LIFT YOKE F/JUK
B-2402-372-000	BTN LVR HLOLD SHAFT
B-2402-716-000	THREAD GUIDE F/JUKI
B-2402-771-000	NEEDLE PLATE
B-2403-980-000	CAM STUD F/JUKI
B-2404-280-000	CAM ROLLER F/JUKI
B-2404-372-L00	SPRING F/JUKI
B-2404-373-000	THR TRIM CONN F/JUKI
B-2404-373-000A	TRIM CONN LINK F/JUK
B-2404-373-R00	CONNECTING LINK F/JK
B-2404-771-000	BOBBIN THRD TRIMMER
B-2405-372-L00	BUT CLMP LVR F/JUKI
B-2405-761-000	PULL-OFF F/JUKI
B-2405-771-000	BOBBIN THREAD PULLER
B-2406-372-0A0	KNIFE ASSEMBLY F/JUK
B-2406-372-L00	SHNK BUT HOLD CLMP
B-2406-373-0A0	KNIFE ASSEMBLY F/JKI
B-2406-761-0A0	BOBBN THRD KNF BLADE
B-2406-771-0A0	BOBBIN THREAD KNIFE
B-2406-980-000	CONN RING F/JUKI
B-2408-372-000	SHK BUTTON GURD F/JK
B-2408-761-000	COUNTER KNIFE
B-2408-771-000	COUNTER KNIFE
B-2408-771-000A	COUNTER KNIFE F/JUKI
B-2409-372-LA0	FEED PLATE F/JUKI
B-2410-372-00C	BUTTON SUPPORT F/JKI
B-2410-372-00D	PLATE F/JUKI
B-2410-372-L0A	LOW BLOCK F/JUKI
B-2410-372-L0B	MEDIUM BLOCK F/JUKI
B-2410-372-L0C	HIGH BLOCK F/JUKI
B-2410-980-000	TENSION SPRING F/JUK
B-2413-053-000	REAR LIFT BAR F/JUKI
B-2414-280-0A0	KNIFE DRIVING LEVER
B-2415-280-000	THREAD CUTTER LEVER

PART NUMBER	DESCRIPTION
B-2415-280-0A0	KNIFE DRIVING LEVER
B-2416-280-000	COLLAR F/LK-280
B-2417-771-000	THRD GUIDE F/LBH771
B-2418-280-000	LINK F/LK-280
B-2419-372-A00	BUTTON HOLD SHOE F/J
B-2419-372-B00	BUTTON HOLD SHOE F/J
B-2419-372-C00	SHANK BUT ADAPTR F/J
B-2421-205-0A0	MOV KNIFE ASY F/JUKI
B-2421-210-000	MOVING KNIFE F/JUKI
B-2421-210-AA0	MOVING KNIFE F/JUKI
B-2421-280-000	THREAD CUTTER F/JUKI
B-2421-280-0A0	MOVING KNIFE F/JUKI
B-2421-771-000	TRIP LATHC(PICKER)
B-2423-232-000	NEEDLE THREAD KNIFE
B-2423-280-000	WASHER F/JUKI
B-2423-280-00A	WASHER F/JUKI
B-2423-280-00B	WASHER F/LK-280
B-2423-280-00C	WASHER F/JUKI
B-2423-280-00D	WASHER F/JUKI
B-2424-210-000	MOVING KNIFE F/JUKI
B-2424-210-A00	STATION KNIFE F/JUKI
B-2424-232-000	BOBBIN THREAD KNIFE
B-2424-280-000	COUNTER KNIFE F/JUKI
B-2424-280-0A0	KNIFE F/JUKI
B-2426-232-000	NDL BUSHING F/JUKI
B-2426-280-000	NDL HOL GUIDE F/JUKI
B-2426-280-000-B	LRG HOL BUSHING F/JK
B-2426-280-00B	.078" HOL BUSHING
B-2426-280-00C	HOLE GUIDE F/JUKI
B-2426-771-000	BOBBIN PR PLATE F/JU
B-2426-980-000-C	LRG HOL BUSHING F/JK
B-2428-372-L00	SCREW F/JUKI
B-2429-372-L00	SCREW F/JUKI
B-2440-372-0A0	BUTN NECK ATTCH F/JK
B-2440-372-0B0	BUTTON CLAMP F/JUKI
B-2442-372-0A0	MIDDLE GUIDE ASM F/J
B-2442-373-0A0	MID GUIDE ASM F/JUKI
B-2446-372-000	SCREW (GUIDE PIN)
B-2447-372-000	SHANKING FOOT F/JUKI
B-2470-562-B00	INSIDE FOOT F/JUKI
B-2501-280-000	ROLL SHAFT F/JUKI
B-2502-280-00B	FEED CAM ROLLER
B-2502-280-B0B	FD CAM ROLLER F/JUKI
B-2503-352-000	STOPPER F/JUKI
B-2507-180-0A0	ROCKER F/MBH-180
B-2507-372-000	FEED CAM ROLLER F/JU
B-2510-352-000	LOOPER HOLDER
B-2512-804-000A	UPPER LOOPER GUIDE
B-2512-804-0B0	LPR HOLDER ASLY F/JK
B-2513-026-F00	LOOPER (A) F/JUKI
B-2514-026-000	LOOPER F/JUKI

PART NUMBER	DESCRIPTION
B-2514-803-000	BLIND LOOPER F/JUKI
B-2514-860-000	LOOPER F/JUKI
B-2514-860-G00	LOOPER F/JUKI
B-2515-026-F00	LOOPER (C) F/JUKI
B-2515-280-000	GUIDE PLATE F/JUKI
B-2517-352-000	LOOPER HOLDER F/JUKI
B-2517-804-000	LPR HOLDER ASLY F/JK
B-2517-804-0A0A	LPR HOLDER ASLY F/JK
B-2518-352-000	TAKE UP F/JUKI
B-2518-804-000	UPPER LOOPER HOLDER
B-2518-804-000A	UPR LPR SUPPRT ARM
B-2518-804-0A0B	UP LPR HOLDER F/JUKI
B-2519-280-000	FEED PLATE F/LK-280
B-2519-280-000B	FEED PLATE F/JUKI
B-2519-280-000D	FEED PLATE F/JUKI
B-2519-804-000	UPPER LOOPER F/JUKI
B-2519-814-000	LOOPER F/JUKI
B-2520-352-000	UPPER LOOPER F/JUKI
B-2520-353-000	BLIND LOOPER F/JUKI
B-2520-704-000	HOLDER F/JUKI
B-2520-704-0A0	HOLDER F/JUKI
B-2521-280-000	REGULATOR F/JUKI
B-2521-352-000	LOWER LOOPER F/JUKI
B-2521-704-0A0	SPACER F/JUKI
B-2521-804-000	LOWER LOOPER F/JUKI
B-2521-814-000B	LOOPER F/JUKI
B-2522-372-000	LEVER PLATE F/JUKI
B-2522-373-000	FEED PLATE F/JUKI
B-2522-373-000A	FEED PLATE F/JUKI
B-2522-704-000	LOOPER THRD TAKE-UP
B-2523-180-000	FIRST LOOPER F/JUKI
B-2523-372-000	STUD F/JUKI
B-2523-704-000	THR TAKE UP F/JUKI
B-2523-804-000	THREAD TAKE UP
B-2524-180-000	SECOND LOOPER F/JUKI
B-2524-372-000	BLOCK F/JUKI
B-2525-357-000	OIL SEAL F/JUKI
B-2525-372-000	FEED INDICATOR F/JUK
B-2526-372-000	PIN F/JUKI
B-2529-372-000	FEED PLATE F/JUKI
B-2529-373-000	FEED PLATE F/JUKI
B-2529-373-B00	FEED PLATE F/JUKI
B-2530-372-0A0	CAM BOSS F/JUKI
B-2531-704-000	CHAIN WASHER F/JUKI
B-2531-704-0A0	CHAIN WASHER F/JUKI
B-2539-280-000	STUD F/JUKI
B-2540-372-000	STUD F/JUKI
B-2541-372-000	SNAP RING F/JUKI
B-2542-372-000	ARCH F/JUKI
B-2542-372-L00	ARCH F/LEWIS
B-2543-280-000	WORK CLAMP FOOT HOOK

PART NUMBER	DESCRIPTION
B-2543-372-000	STOPPER PIN F/JUKI
B-2543-372-L00	STOPPER PIN F/JUKI
B-2544-372-000	PRES ADJ BAR F/JUKI
B-2545-280-000	SPRING F/LK280
B-2545-372-000	ADJ SPRING F/JUKI
B-2545-980-000	
B-2546-280-000	PRESSER FOOT SUSP
B-2546-372-000	BUTN CLAMP LIFT HOOK
B-2547-372-000	BUT CLMP FASTNER F/J
B-2547-372-0B0	FLAT BUT CLAMP F/JUK
B-2547-373-N00	BUTTON CLAMP BASE
B-2548-280-000	BALL RETAINER F/JUKI
B-2548-372-000	BUT CL STOPPER F/JUK
B-2549-280-000	BALL F/FT MNT F/JUKI
B-2549-372-000	SCREW F/JUKI
B-2550-232-000	RIGHT CLAMP F/JUKI
B-2550-232-0A0	SET CLAMPS F/JUKI
B-2551-232-000	LEFT CLAMP F/JUKI
B-2551-280-000	WORK CLAMP FOOT RIGT
B-2552-280-000	WORK CLAMP FOOT LEFT
B-2552-372-000	BUT CLMP SLIDE F/JUK
B-2552-372-BA0	SNAP CLAMP F/JUKI
B-2553-372-000	CNTR FNGR NUT F/JUKI
B-2555-372-000	LEFT BUTN CLAMP JAW
B-2555-372-0A0	LEFT BUTN CLMP JAW
B-2555-372-B00	SNP FSTNR CLMP JAW L
B-2555-372-R00	LEFT JAW CLAMP F/JUK
B-2556-372-000	L JAW SPRING F/JUKI
B-2557-372-000	RIGHT BUTN CLAMP JAW
B-2557-372-0A0	RIGHT BUTN CLAM JAW
B-2558-372-000	RT JAW SPRING F/JUKI
B-2559-372-000	PIN F/JUKI
B-2561-372-000	PIN F/JUKI
B-2602-372-000	PLUNGER LEVER F/JUKI
B-2604-280-000	STOP ROD LINK F/JUKI
B-2604-280-000A	STP LINK ROD F/JUKI
B-2604-372-000	STOP MOTION PLUNGER
B-2604-980-000	STOP LINK ROD F/JUKI
B-2605-280-000	DR LEVER F/JUKI
B-2605-280-000A	DR LEVER F/JUKI
B-2605-280-0A0	DRV LVR ASSMB F/JUKI
B-2605-372-000	ROD F/JUKI
B-2605-980-000	SCREW F/JUKI
B-2606-280-000	SPRING F/LK280
B-2606-372-000	DISC SPRING F/JUKI
B-2607-280-000	WASHER F/JUKI
B-2607-372-000	RUBBER CUSHION F/JKI
B-2608-280-000	RUBBER CUSHION F/JKI
B-2608-372-000	SPRING PIN F/JUKI
B-2609-372-000	SPRING F/JUKI
B-2609-980-000	SLIDE BLOCK F/JUKI

PART NUMBER	DESCRIPTION
B-2610-280-000	SPRING F/LK280
B-2610-980-000	TENSION SPRING F/JUK
B-2611-372-000	LEVER F/JUKI
B-2611-980-000	DR PUL PR PLATE F/JU
B-2611-980-000A	DR PUL PR PLATE F/JU
B-2611-980-0A0A	DR PUL PR PLATE F/JU
B-2613-232-000	SCREW F/JUKI
B-2613-280-000	ROLLER F/JUKI
B-2614-280-000	REG CAM SHAFT F/JUKI
B-2614-980-000	REG CAM SHAFT F/JUKI
B-2615-280-000	STOP RING F/JUKI
B-2615-372-000	TRIP LEVER PIN F/JUK
B-2616-372-000	SPRING F/JUKI
B-2617-980-0A0	LEVER ASLY F/JUKI
B-2619-232-000	PRESSR SPRING F/JUKI
B-2619-280-000	STARTING LEVER
B-2620-980-000	CONN LEVER F/JUKI
B-2622-280-000A	SPRING F/LK280
B-2622-980-000	PLATE HLDER PIN F/JK
B-2624-280-000	PIN F/LK280
B-2624-372-000	SCREW F/JUKI
B-2624-980-000	DRIVNG PLATE F/LK280
B-2625-980-000	SPRING F/JUKI
B-2629-980-000	SPRING F/JUKI
B-2630-980-000	PRESS PLATE F/JUKI
B-2636-372-000	LEVER F/JUKI
B-2637-372-000	SLIDE BLOCK F/JUKI
B-2638-372-000	STUD F/JUKI
B-2639-372-0A0	FRIC PL HOLDER ASLY
B-2643-372-000	SPRING F/JUKI
B-2701-180-A00	1/4 KNIFE F/MBH180
B-2701-180-B00	3/8 KNIFE F/MBH180
B-2701-180-C00	1/2 KNIFE F/MBH180
B-2701-180-D00	9/16 KNIFE F/MBH180
B-2701-180-E00	5/8 KNIFE F/MBH180
B-2701-180-F00	1/4 KNIFE F/MBH180
B-2701-180-G00	7/8 KNIFE F/MBH180
B-2701-180-H00	1" KNIFE F/MBH180
B-2701-180-I00	7/16" KNIFE F/MBH180
B-2701-180-J00	1-1/8 KNIFE F/MBH180
B-2701-180-K00	3/8 KNIFE F/MBH180
B-2701-180-L00	1/2 KNIFE F/MBH180
B-2701-180-M00	5/8 KNIFE F/MBH180
B-2701-180-N00	3/4 KNIFE F/MBH180
B-2701-180-P00	7/8" KNIFE F/MBH180
B-2701-180-Q00	1" KNIFE F/MBH180
B-2701-180-R00	1-1/8 KNIFE F/MBH180
B-2701-180-S00	1-1/4 KNIFE F/MBH180
B-2701-180-T00	1-3/8" KNIFE FMBH180
B-2701-180-V00	9/16" KNIFE F/MBH180
B-2702-047-F00	1/4" KNIFE F/LBH761

PART NUMBER	DESCRIPTION
B-2702-047-I00	7/16 KNIFE F/JUKI
B-2702-047-K00	3/8" KNIFE F/LBH761
B-2702-047-L00	1/2" KNIFE F/LBH761
B-2702-047-M00	5/8" KNIFE F/LBH761
B-2702-047-N00	3/4" KNIFE F/LBH761
B-2702-047-P00	7/8" KNIFE F/LBH761
B-2702-047-Q00	1" KNIFE F/LBH761
B-2702-047-R00	1-1/8 KNIFE F/LBH761
B-2702-047-S00	1-1/4 KNF F/LBH761
B-2702-047-U00	1-1/2" KNIFE F/JUKI
B-2702-047-V00	9/16" KNIFE F/LBH761
B-2709-771-000	DR LEVER SHAFT F/JUK
B-2718-761-000	TORSION SPRING F/JKI
B-2730-761-000	STOP STUD F/JUKI
B-2733-761-000	FINGER F/JUKI
B-2745-771-F00	1/4" KNIFE FOR JUKI
B-2745-771-K00	3/8" KNIFE FOR JUKI
B-2745-771-N00	3/4" KNIFE F/JUKI
B-2746-771-000	KNIFE GUARD F/JUKI
B-3009-980-000	CLUTCH SPRING F/JUKI
B-3009-980-00B	CLUTCH SPRING F/JUKI
B-3028-280-000	LATCH F/LK980
B-3030-980-000	SAFETY PLATE BRACKET
B-3101-280-000	BRACKET F/SAFETY GRD
B-3101-280-0A0	SAFETY PLATE F/LK980
B-3101-372-0A0	SAFETY PLATE F/JUKI
B-3101-704-000	THR TENSION ASY F/JU
B-3101-704-0B0	RED TENSION COMPLETE
B-3101-716-0B0	TENSION F/JUKI
B-3101-804-000	RED TENSION SPRING
B-3101-804-0A0	TENSION F/JUKI
B-3102-704-0A0	TENSION ASSY
B-3102-704-0B0	YELLOW TENSION UNIT
B-3102-804-000	YELOW TENSION SPRING
B-3102-804-0A0	TENSION F/JUKI
B-3103-704-0A0	TENSION F/JUKI
B-3103-704-0B0	BLUE TENSION UNIT
B-3103-804-000	BLUE TENSION SPRING
B-3103-804-0A0	TENSION F/JUKI
B-3104-372-000	PLUNGER F/JUKI
B-3105-804-000	TENSION POST F/JUKI
B-3106-019-000	SCREW F/JUKI
B-3106-704-00A	TEN KNOB (RED) F/JKI
B-3106-704-00B	TEN KNOB(BLUE) F/JKI
B-3106-704-00C	TEN KNOB (YEL) F/JKI
B-3106-816-000	TENSION POST NUT
B-3107-373-000	THREAD GUIDE F/JUKI
B-3107-704-000	TENS DISC P TUBE F/J
B-3107-804-000	TENSION DISC TUBE
B-3108-372-000	THREAD GUIDE F/JUKI
B-3108-704-000	THR GUID DISC F/JUKI

PART NUMBER	DESCRIPTION
B-3108-804-000	THREAD GUIDE DISC
B-3109-372-0A0	THREAD GUIDE F/JUKI
B-3110-372-000	TENSION SPRING
B-3111-126-0A0	TENSION COMPL F/JUKI
B-3111-552-000	TENS BARREL F/JUKI
B-3111-552-0A0	TENSION CMPLT F/JUKI
B-3111-552-B00	TENS BARREL F/JUKI
B-3112-704-000	TEN SPR BUSHING F/JK
B-3112-761-000	CHECK SPRING
B-3114-232-000	SPRING F/JUKI
B-3114-761-000	FRAME THREAD GUIDE
B-3115-552-000	TENSION POST F/JUKI
B-3115-761-000	THREAD GUIDE F/JUKI
B-3116-125-000	TENSION NUT
B-3118-051-000	TAKE-UP SPRING
B-3118-552-000	TENSION REL PIN F/JK
B-3118-552-A00	TENSION RELEASING
B-3118-552-B00	TEN RELEASE PIN
B-3118-552-C00	TEN RELEASE PIN
B-3118-552-E00	TENS REL PIN F/JUKI
B-3119-352-000	TENSION POST F/JUKI
B-3119-771-000	TENSION NUT F/JUKI
B-3120-125-000	TENSION DISC STOP
B-3120-372-000	LENS F/JUKI
B-3120-372-0A0	EYE GUARD F/JUKI
B-3120-704-000	TENS SPR FELT F/JUKI
B-3121-051-000	THR CONTRL BASE F/JK
B-3121-051-0A0	TENSION UNIT F/JUKI
B-3121-053-000	TENION ASLY F/JUKI
B-3121-053-0A0	TENSION UNIT F/JUKI
B-3121-372-000	INST PLATE F/JUKI
B-3121-512-0A0	TENSION UNIT ASMBL
B-3121-512-0B0	TENSION UNIT F/JUKI
B-3122-027-000	TENSION POST F/JUKI
B-3122-053-000	THREAD REL PIN F/JKI
B-3123-051-000	TENSION POST STUD
B-3123-352-000	TENSION POST
B-3123-512-000	TENSION STUD POST
B-3124-512-000	THREAD TENSION POST
B-3124-512-00B	THREAD TENSION POST
B-3125-012-000	TENSION POST NUT
B-3126-012-000	TENSION DISC F/JUKI
B-3126-051-000	TENSION DISC
B-3126-352-000	JUKI TENSION DISC
B-3127-051-000	THREAD REL PIN F/JUK
B-3128-012-000	CHECK SPRING F/JUKI
B-3128-027-000	TAKEUP SPRING F/JUKI
B-3128-051-000	THRD TAKE-UP SPRING
B-3128-057-000	CHECK SPRING F/JUKI
B-3128-057-B00	CHECK SPRING F/JUKI
B-3128-127-000	CHECK SPRING F/JUKI

PART NUMBER	DESCRIPTION
B-3128-232-000	TAKE-UP SPRING F/JKI
B-3128-512-000	TAKE UP SPRING
B-3128-520-000	HEAVY CHECK SPRING
B-3128-527-000	TAKE-UP SPRING F/JUK
B-3128-581-000	TAKE UP SPRING F/JKI
B-3129-012-000	TEN SPRING F/JUKI
B-3129-012-A00	TENSION SPRING
B-3129-012-B00	TENSION SPRING
B-3129-053-000	TENSION SPRING
B-3129-526-000	TENS SPRING F/JUKI
B-3130-372-000A	FINGER GUARD F/JUKI
B-3130-980-000	NEEDLE GUARD F/JUKI
B-3131-051-000	SPRING PIN F/JUKI
B-3132-012-000	TENSION DISC F/JUKI
B-3132-051-000	TENS RELEASE WASHER
B-3132-552-000	TENS RELEASE WASHER
B-3134-051-000	THR REL LEVER F/JUKI
B-3134-415-000	TEN REL LINK F/JUKI
B-3134-521-000	TEN REL LEVER F/JUKI
B-3137-051-0A0	THR CONTRL DISC F/JK
B-3138-051-000	ADJ PLATE F/JUKI
B-3138-512-000	ADJ PLATE F/JUKI
B-3148-123-000	TENSION DISC F/JUKI
B-3149-123-000	TENS SPRING F/DDL555
B-3149-123-A00	TENS SPRING F/JUKI
B-3149-123-B00	TENSION SPRING F/JKI
B-3201-012-0A0	BOBBIN WINDER F/JUKI
B-3201-280-0A0	BOB WNDRF/LK980 JUKI
B-3203-280-000	SPRING F/JUKI
B-3204-280-000	B/W SPINDLE F/JUKI
B-3206-280-000	B/W TRIP LATCH F/JUK
B-3207-280-000	TRIP LATCH F/JUKI
B-3208-280-000	LATCH ADJ SCREW F/JU
B-3209-555-000	B/W LATCH F/JUKI
B-3211-280-0A0	B/W THR GD F/LK-280
B-3211-980-000	THR GD BRACKET F/JUK
B-3212-210-000	FRICTION WHEEL F/JU
B-3214-047-000	TENSION DISC F/JUKI
B-3216-047-000	TENSION NUT F/JUKI
B-3218-232-000	TENSION SPRING F/JKI
B-3301-051-0B0	3-SP THR STAND F/JUK
B-3301-704-0AC	4SP THR STAND F/JUKI
B-3301-704-LA0	4SP THR STAND F/JUKI
B-3301-716-LA0	5SP THR STAND F/JUKI
B-3301-843-LA0	6-SP THRD STND F/JUK
B-3303-704-L00	SPOOL PLATFORM F/JU
B-3311-012-000	PLATFORM FELT
B-3311-804-000	THREAD GUIDE F/JUKI
B-3312-012-000	RUBBER CONE HOLDER
B-3312-012-S00	SPOOL HOLDER F/JUKI
B-3319-704-L00	THREAD GUIDE F/JUKI

PART NUMBER	DESCRIPTION
B-3320-704-L00	SPOOL PIN W/NUT F/JU
B-3401-027-0B0	KNEE LIFTER ASM F/JU
B-3401-053-000	K/L LEVER F/JUKI
B-3403-027-000	ANGLE ROD F/JUKI
B-3405-027-0A0	KNEE PLATE
B-3409-027-000	K/L SPRING F/JUKI
B-3409-053-000	LEVER F/JUKI
B-3410-027-000	ROD & SCREW F/JUKI
B-3410-051-000	K/L REAR LEVER F/JUK
B-3413-051-000	REAR LIFT BAR F/JUKI
B-3413-053-000	REAR LIFT BAR F/JUKI
B-3414-051-000	SPRING F/LU562-3
B-3415-552-000	LVR CONN RD F/DD552
B-3416-051-000	LIFT BAR ROLLER F/JU
B-3417-051-000	LIFT BAR ROLLER F/JU
B-3418-552-000	SCREW F/JUKI
B-3418-562-000	LIGHT STUD F/JUKI
B-3419-552-0A0	K/L ROD ASLY F/JUKI
B-3420-552-0A0	KNEE LIFTER ASY F/JU
B-3420-552-0A0-A	KNEE LIFTER ASY F/JU
B-3420-555-0A0	KNEE LIFTER ASY F/JU
B-3421-552-0A0	PLUNGER F/JUKI
B-3421-555-000	PLUNGER F/JUKI
B-3421-555-0A0	PLUNGER F/JUKI
B-3426-552-000	RING F/JUKI
B-3427-122-000	KN LIFT BKT F/JUKI
B-3429-552-000	SPRING F/JUKI DDL552
B-3501-555-0A0	LUB OIL PUMP ASM F/J
B-3509-704-000	FILTER PAPER F/JUKI
B-3510/3535-352-000	FILTER & SCREEN F/JK
B-3510-352-0A0	FILTER ASM F/JUKI
B-3514-412-000	OIL ADJ SCREW F/JUKI
B-3515-804-000	VINYL TUBE F/JUKI
B-3520-804-000	FILTER SCRNB(B) F/JKI
B-3521-552-000	OIL TUBE F/JUKI
B-3525-980-0A0	DR PUL PR PLATE F/JU
B-3525-980-0B0	DR PUL PR PLATE F/JU
B-3525-980-0B0A	DR PUL PR PLATE F/JU
B-3534-155-000	PLUNGER F/JUKI
B-3535-352-000	FILTER PAPER F/JUKI
B-3901-880-A00	SPREADER "A" F/JUKI
B-4001-180-000	THRD TRIM KNF F/JUKI
B-4002-180-000	TRIMMER HOOK F/JUKI
B-4101-352-000	CRANK ROD CONN F/JKI
B-4102-352-000	UP KN ECC CAM F/JUKI
B-4102-352-0A0	UP KN ECC CAM F/JUKI
B-4106-804-000A	KNIFE SUPPORT F/JUKI
B-4106-816-000	UP KNF SUPPORT F/JUK
B-4106-816-000A	KNIFE SUPPORT F/JUKI
B-4107-804-000	UPR KNIFE PRES PLATE
B-4107-804-000A	UPR KNF PRSR PLT F/J

PART NUMBER	DESCRIPTION
B-4108-352-000	UPPER KNIFE F/JUKI
B-4108-352-00A	KNIFE F/JUKI
B-4108-352-00B	KNIFE F/JUKI
B-4108-352-00C	HIGH SPD KNIFE F/JKI
B-4108-352-00D	CARBIDE KNIFE F/JUKI
B-4108-352-K0C	HSS UP KNIFE F/JUKI
B-4108-352-K0D	KNIFE F/JUKI
B-4108-804-000	UPR KNIFE GUIDE F/JK
B-4108-804-000A	KNIFE GUARD F/JUKI
B-4109-804-000	UPR KNF WASHR F/JUKI
B-4111-804-000	UPPER KNIFE F/JUKI
B-4111-804-00A	CT UP WIDE KNF F/JUK
B-4111-804-00B	UPPER KNIFE F/JUKI
B-4111-804-00C	NRW CAR KNIFE F JUKI
B-4111-804-00E	CARBIDE TIPPED KNIFE
B-4117-352-000	STOP SCREW F/JUKI
B-4117-804-000	LWR KNIFE PRESSR PLT
B-4118-804-000	LOWER KNIFE F/JUKI
B-4118-804-00B	LOWER KNIFE F/JUKI
B-4118-804-00C	LOWER KNIFE F/JUKI
B-4120-816-000A	NEEDLE GUARD F/JUKI
B-4120-816-D0BA	NEEDLE GUARD F/JUKI
B-4120-816-F0CA	GUARD F/JUKI
B-4121-052-A00	1/8" KNIFE F/JUKI
B-4121-052-B00	1/4" KNIFE F/JUKI
B-4121-352-000	KNIFE CLAMP F/JUKI
B-4121-522-000	KNIFE F/JUKI
B-4121-804-000	NDL GUARD A F/JUKI
B-4121-804-00B	NEEDLE GUARD "B" F/J
B-4121-816-000	NEEDLE GUARD F/JUKI
B-4122-352-000	LOWER KNIFE F/JUKI
B-4122-352-00A	KNIFE F/JUKI
B-4122-352-00C	LOWER KNIFE F/JUKI
B-4122-352-00D	CT KNIFE F/JUKI
B-4122-354-00A	KNIFE F/JUKI
B-4122-357-00D	KNIFE F/JUKI
B-4122-522-000	WASHER F/JUKI
B-4122-816-000	NEEDLE GUARD F/JUKI
B-4123-352-000	STOPPER SPRING F/JUK
B-4123-804-000	ROLLER STUD F/JUKI
B-4131-357-000	NDL GD ADJ GUIDE
B-4145-530-B00	CL CUT KNIFE F/JUKI
B-4401-372-0A0	LIFT CRANK F/JUKI
B-4406-372-0A0	BUT CLMP LINK LEVER
B-4411-372-000	LIFTING LINK F/JUKI
B-4411-372-000-A	LINK F/JUKI
B-4411-372-000A	LIFTING LINK F/JUKI
B-4412-372-000	BTN CLMP LEVER F/JUK
B-4412-372-000A	BTN CLMP LEVER F/JUK
B-4415-372-000	LIFT LVR STOP F/JUKI
B-4416-372-000	BUTN CLMP ROD F/JUKI

PART NUMBER	DESCRIPTION
B-4417-372-000	LIFT ROD ROLLER F/JK
B-4418-372-000	WASHER F/JUKI
B-4419-372-000	LIFT LVR SPRING F/JK
B-4420-373-000	RUBBER CUSHION F/JUK
B-5014-100-000	SNAP RING F/JUKI
B-7252-781-000	BELT F/JUKI
B-8131-019-000	CHAIN SET F/JUKI
B-8133-019-000	"S" HOOK F/JUKI
B-8207-804-000A	LWR CHIP CHUTE F/JUK
B-8209-804-000	ISOLATOR F/JUKI
B-8209-804-0A0	ISOLATOR F/JUKI
B-8210-372-0A0	BUTN TRAY ASLY F/JUK
B-8212-125-000	RUBBER HINGE F/JUKI
B-8213-125-000	METAL HINGE F/JUKI
B-8213-512-000	METAL HINGE F/JUKI
B-8213-512-0A0	RUBBER & HINGE SET
B-8215-704-000	GASKET F/JUKI
B-8216-804-0A0-A	JUKI SHAFT SCREW ASY
B-8216-804-0A0A	FAN SHFT SCRW ASMLY
B-8217-053-000	DRIP PAN F/JUKI
B-8217-804-000	COOLING FAN F/JUKI
B-8217-804-000A	COOLING FAN F/JUKI
B-8217-804-0A0	COOLING FAN F/JUKI
B-8218-125-000	GASKET F/JUKI
B-8218-552-000	GASKET F/JUKI
B-8221-804-0A0	COLLAR ASLY F/JUKI
B-8226-125-000	RUBBER CUSHION F/JKI
B-9101-357-KA0	SWING GUIDE F/JUKI
B-9112-804-000	WRENCH F/JUKI
B-9117-001-000	BOBBIN F/JUKI LK-232
B-9117-007-000	BOBBIN F/JUKI
B-9117-007-000A	ALUM BOBBIN F/JUKI
B-9117-012-000	BOBBIN F/JUKI
B-9117-012-000W	SILVER BOBBINS
B-9117-039-000	BOBBIN F/JUKI
B-9117-051-000	BOBBIN F/JUKI
B-9117-057-000	BOBBIN F/JUKI
B-9117-141-E00	ALUMINUM BOBBIN
B-9117-155-000	BOBBIN F/JUKI
B-9117-201-000	BOBBIN F/JUKI
B-9117-552-A00	ALUM BOBBIN F/JUKI
B-9117-563-000	BOBBIN F/JUKI
B-9117-563-000G	BOBBIN F/JUKI
B-9117-563-000P	ALUM BOBBIN F/JUKI
B-9117-563-000P-4	AL BOBBN 4LONG HOLES
B-9117-563-000S	BOBBIN W/O HOLES
B-9117-563-000W	BOBBIN F/JUKI
B-9121-012-000	OILER F/JUKI
B-9121-012-0A0	OILER F/JUKI
BC-NJ380	BOBBIN CASE F/NAKAJ
BT-0500300-EA	OIL TUBE F/JUKI

PART NUMBER	DESCRIPTION
BT-0500300-EO	OIL TUBE F/JUKI
C115-39202	CHAIN LOOPER F/GALK
C118-88609	SPREADER
CQ-2020000-00	OIL WICK F/JUKI
CS-0510713-SC	SPRING RETAIN COLLAR
CS-0790613-TH	COLLAR F/JUKI
CS-079061A-TH	COLLAR F/JUKI
CS-111101D-SH	THRUST COLLAR A F/JU
D-1109-555-D0I	THROAT PLATE F/JUKI
D-1109-555-E0L	PLATE F/JUKI
D-1201-055-B00	UP MAIN SHAFT F/JUKI
D-1208-555-D00	RUBBER/METL OIL SEAL
D-1217-555-C00	HAND WHEEL F/JUKI
D-1405-L7A-M00	N/B THR GUIDE F/JUKI
D-1419-555-000	THR GUIDE F/JUKI 555
D-1419-555-D00	N/B THR GUIDE F/JUKI
D-1421-555-D00	FINGER GUARD F/JUKI
D-1453-055-B00	UPPER FD ROD F/JUKI
D-1455-055-B00	LIFT ROCK BUSH F/JKI
D-1456-055-B00	SCREW F/JUKI
D-1457-055-B00	WASHER F/JUKI
D-1458-055-B00	WING NUT F/JUKI
D-1463-241-E00	JUKI BRACKET GUIDE
D-1470-241-E0A	WALKING FOOT F/JUKI
D-1524-415-0A0	PRESSER FOOT F/JUKI
D-1524-415-BAA	PRESSER FOOT F/JUKI
D-1524-415-BBA	FOOT w/WIRE GUARD
D-1524-415-BBC	PR FOOT w/guard F/JU
D-1524-555-DA0	PRESSER FOOT F/JUKI
D-1609-415-B00	FEED DOG F/JUKI
D-1609-415-B0H	FEEDER F/JUKI
D-1609-415-H0B	FEED DOG F/JUKI
D-1613-241-E0B	FEEDER F/JUKI
D-1613-357-H0B-A	MAIN FEED DOG F/JUKI
D-1614-357-H0B	DIFF FEEDER F/JUKI
D-1624-555-B00	SPRING F/JUKI
D-1818-282-N00	SHUTTLE HOOK F/JUKI
D-1830-141-EA0-VAL	HOOK F/JUKI
D-1830-241-EA0-VAL	HOOK F/JUKI
D-1830-415-BAH	HOOK F/JUKI UNDERTR
D-1830-415-BAH-VAL	HOOK F/JUKI
D-1830-555-BA0	HOOK F/JUKI
D-1830-555-BA0-CM	CERLIANI HOOK
D-1830-555-BA0-VAL	VALUE-LINE HOOK F/JU
D-1830-555-BAG	HOOK F/JUKI
D-1830-555-DA0	HOOK F/JUKI
D-1830-555-DA0-CM	CERLIANI HOOK F/JUKI
D-1830-555-DAB	HOOK F/JUKI
D-1830-555-DAC	HOOK F/JUKI
D-1830-555-DAC-CM	CERLIANI HOOK
D-1830-555-DAC-VAL	HOOK F/JUKI

PART NUMBER	DESCRIPTION
D-1830-560-EA0	HOOK F/JUKI
D-1835-555-B00	POSITION FINGER F/JK
D-1835-555-B0H	POSITION FINGER F/JK
D-1835-555-BOH	POSITION FINGER F/JK
D-1836-555-B00	THREAD GUIDE F/JUKI
D-1837-141-EA0	BOBBIN CASE F/JUKI
D-1837-415-DAL	BOBBIN CASE F/JUKI
D-1837-555-BA0	NBL BOB CASE F/JUKI
D-1837-555-BAA	NBL BOB CASE F/JUKI
D-2030-481-C00	LOOPER F/JUKI
D-2104-555-C00	WIPER F/JUKI
D-2107-555-B00	WIPER LNK SHAFT F/JK
D-2119-555-C00	SWITCH F/JUKI
D-2401-530-D00	THR TRIM KNIFE F/JUK
D-2402-415-BA0	KNIFE F/JUKI
D-2402-415-BAH	MOV KNIFE ASY F/JUKI
D-2402-415-DAL	MOV KNIFE ASY F/JUKI
D-2402-555-B00A	MOVABLE KNIFE F/JUKI
D-2402-555-B00B	MOVING KNIFE F/JUKI
D-2402-555-BA0	MOVABLE KNIFE F/JUKI
D-2402-555-BAB	TRIMMER F/JUKI
D-2405-415-D0L	THREAD GUIDE F/JUKI
D-2405-481-C00A	COUNTER KNIFE F/JUKI
D-2405-555-B00	THREAD GUIDE F/JUKI
D-2405-555-B00A	KNIFE THRD GD F/JUKI
D-2405-555-B00B	KNIFE THRD GD F/JUKI
D-2406-555-B00	FIXED KNIFE F/JUKI
D-2406-555-D0H	KNIFE F/JUKI
D-2407-415-D00	JUKI THREAD HOLDER
D-2408-555-CA0	PICKER ASSLY F/JUKI
D-2411-555-B00	KNIFE BASE F/JUKI
D-2423-241-E00	JUKI KNIFE(115681000
D-2423-280-00C	WASHER F/JUKI
D-2424-241-E00	JUKI KNIFE(115682000
D-2443-241-E00	JUKI SCREW
D-2506-373-L00	FEED CAM F/JUKI
D-2529-372-C00	FEED PLATE F/JUKI
D-2529-373-B00	FEED PLATE F/JUKI
D-2529-373-C00	FEED PLATE F/JUKI
D-2547-372-CB0	GNT FLT BT CLMP/JUKI
D-2556-372-C00	LFT JAW SPRING F/JUK
D-2558-372-C00	RT JAW SPRING F/JUKI
D-3128-555-D00	TAKEUP SPRING F/JUKI
D-3129-555-D00	TENSION SPRING F/JUK
D-3161-555-BA0	1st TEN POST ASM F/J
D-3168-555-B00	TENSION SPRNG F/JUKI
D-3168-555-H0B	TENSION SPRING F/JUK
D-3201-555-DA0	SMALL BOBBIN WINDER
D-3301-555-DA0	TWO SPL THREAD STAND
D-8229-555-E00	RUBBER CUSHION
D-9101-357-KA0	SWING GUIDE F/JUKI

PART NUMBER	DESCRIPTION
D-9117-141-E00	ALUM BOBBIN F/JUKI
D-9117-141-E00-4	ALUM BOBBINS W/4HOLE
DF28403	DIF FEEDER F/KINGTEX
DF8040T	DIF FD DOG F/KINGTEX
DF814BE	DIF FEED F/KINGTEX
DF85100	DIF FEED F/KINGTEX
DF85308	DIF FEEDER F/KINGTEX
DF85902	FEEDER F/KINGTEX
DF86009	DIF FEEDER F/KINGTEX
DF90706	DIFF FEED F/KINGTEX
FD60821	MAIN FEEDER F/KINGTX
FD60822	MAIN FEED F/KINGTEX
FD60823	MAIN FEEDER F/KINGTX
FD60825	MAIN FEED F/KINGTEX
FD60829	MAIN FEEDER F/KINGTX
FD60830	MAIN FEED F/KINGTEX
FD60840	MAIN FEED F/KINGTEX
FD60971	MAIN FEED F/KINGTEX
G-1817-875-000	BOBBIN F/JUKI
G-3301-340-0A0	2-SP THR STND F/JUKI
G-5191-100-000	SNAP RING F/JUKI
G-5365-100-000	NUT F/JUKI
GNC605048	NEEDLE CLAMP F/KINGT
GPF605D63	PRESSER FOOT F/KINGT
GTP605D53	THROAT PLATE F/KINGT
GTP605D63	THROAT PLATE F/KINGT
H-001	SWING GUIDE
K80400	LOOPER F/JUKI
LL603884	LOWER LOOPER
M5X10SHCS	SOCKET HEAD CAP SCREW
M6X16SHCS	SOCKET HEAD CAP SCREW
M6X20SHCS	SOCKET HEAD CAP SCREW
M6X25SHCS	SOCKET HEAD CAP SCREW
MAP-80101-ZA0	SW BK TK ATT. F/JUKI
MAS-05108000	SHIRR BLADE F/JUKI
MAS-051080000	SHIRRING BLADE F/JUK
MAS-05209000	SPRING F/JUKI
MAS-05700-0A0	SHIRR ATT F/2516FF6
MAS-057050A0	CABLE ASLY F/JUKI
MAS-05715000	SPRING F/JUKI
MAS-07300-AA0	TURRET FOOT HOLDER
MAS-09202000	MAN LEVER ARM F/JUKI
MAS-092020A0	MAN LEVER ARM F/JUKI
MAT-02105-000	SLIDE BLOCK F/JUKI
MAT-02200-000	FLAT CHN CUTTER F/JU
MAT-02203-000	MOVABLE KNIFE F/JUKI
MAT-02203000	MOVABLE KNIFE F/JUKI
MAT-02204-000	FIXED KNIFE F/JUKI
MAT-02204000	FIXED KNIFE F/JUKI
MAT-02211000	DR LVR SLIDE F/JUKI
MAT-03500-0A0	FLAT AIR CHAIN CUTTR

PART NUMBER	DESCRIPTION
MAT-035000A0	CHN CUT ATT F/JU2500
MAT-03505-000	FIXED KNIFE F/JUKI
MAT-03506-000	MOVABLE KNIFE F/JUKI
MAT-03506000	MOVABLE KNIFE F/JUKI
MAT-03512-000	KN DR LNK BRKT F/JUK
MAT-03512000	BRACKET F/JUKI
MAT-03519-000	COVER F/JUKI
MAT-03521-000	COVER F/JUKI
MAT-03521000	KNF PLATE COVER F/JU
MAT-03605-00A	FIXED KNIFE F/JUKI
MAT-03606-000	MOV KNIFE F/JUKI
MAT-04100-0A0	FLAT CHN CUTTER F/JU
MAT-04200-0B0	SIDE CHN CUTTER F/JU
MAT-61108Z00	SCREW F/JUKI
MAT-61402Z00	THREAD SPRING F/JUKI
MAT-80102-S00	SHIRRING BLADE F/JKI
MAT-80102S00	SHURRING BLADE F/JKI
MAT-80103-H00	GUIDE (ONLY) F/JUKI
MAT-80103-HA0	CLOTH GUIDE F/JUKI
MAT-80103-Z00	UPPER SPRING F/JUKI
MAT-80104-Z00	LOWER SPRING F/JUKI
MAT-80106-Z00	GUARD F/JUKI
MAT-80130-HA0	CLOTH GUIDE F/JUKI
MAT-80202-S00	SHIR BLADE F/JUKI
MAT-80202S00	PRESS PLATE F/JUKI
MAT-8102-S00	WIDE SHIRRNNG BLD F/J
MAZ-02507-000	SPRING F/JUKI
MAZ-08200-0B0	CHAINOFF DEVICE F/JU
MDK260XL050	PULLEY BELT F/JUKI
MO816G	CLOTH GUIDE F/JUKI
MTJ-VM003000	30" V-BELT F/JUKI
MTJ-VM003300	33" V-BELT F/JUKI
MTJ-VM003400	34" V BELT F/JUKI
MTJ-VM003500	35" V BELT F/JUKI
MTJ-VM003600	36" V BELT F/JUKI
MTJ-VM003700	37" V BELT F/JUKI
MTJ-VM003800	38" V BELT F/JUKI
MTJ-VM003900	39" V BELT F/JUKI
MTJ-VM004000	40" V BELT F/JUKI
MTJ-VM004100	41" V BELT F/JUKI
MTJ-VM004200	42" V BELT F/JUKI
MTJ-VM004300	43" V BELT F/JUKI
MTJ-VM004400	44" V BELT F/JUKI
MTJ-VM004500	45" V BELT F/JUKI
MTJ-VM004600	46" V BELT F/JUKI
MTJ-VM004700	47" V BELT F/JUKI
MTJ-VM004800	48" V BELT F/JUKI
MTJ-VM004900	49" V BELT F/JUKI
MTJ-VM005000	50" V BELT F/JUKI
MTJ-VM005200	52" V BELT F/JUKI
MTJ-VM005300	53" V BELT F/JUKI

PART NUMBER	DESCRIPTION
MTJ-VM005600	56" V BELT F/JUKI
MTJ-VM006000	60" V-BELT F/JUKI
NAK-10003	PLATE F/NAKAJIMA
NAK-10006	SLIDE PLATE F/NAK
NAK-10008	FEEDER F/NAKAJIMA
NAK-10018	BOB CASE F/NAKA-280L
NAK-10025	INSIDE FOOT F/NAKAJM
NAK-10026	OUTSIDE FOOT F/NAKAJ
NAK-10058	NEEDLE BAR F/NAKAJI
NAK-10062	THREAD GUIDE
NAK-10082	VIB PRES BAR F/NAK
NAK-1061	B/C POS FINGER F/NAK
NAK-11157	INSIDE BELT F/NAKAJM
NAK-1145	HOOK F/NAKAJIMA
NAK-1145-VAL	HOOK F/NAKAJIMA
NAK-3034	NEEDLE BAR F/NAKAJIM
NAK-3071B	B/C POS FINGER F/NAK
NAK-3082	TENSION SPRING F/NAK
NAK-4091	N/B THR GUIDE F/NAKA
NAK-9070	BOBBIN CASE F/NAKAJM
NAK-S013	SCREW F/NAKAJIMA
NAK-S103	SCREW F/NAKAJIMA
NAK-S176	SCREW
NC603033	NDL CLAMP F/KINGTEX
NC604022	NEEDLE CLAMP F/KINGT
NC604026	NEEDLE CLAMP F/KINGT
NC605020	NDL CLAMP F/KINGTEX
NC605032	NDL CLAMP F/KINGTEX
NC605048	NDL CLAMP F/KINGTEX
NC606032	NEEDLE CLAMP F/KINGT
NC606048	NEEDLE CLAMP F/KINGT
NM-3060810-SF	M6 NUT F/JUKI
NM-6050000-SB	NUT F/JUKI
NM-6050001-SE	NUT F/JUKI
NM-6050001-SP	NUT F/JUKI
NS-2820850-SA	NUT F/JUKI
NS-2820850-SD	NUT F/JUKI
NS-6060310-SP	NUT F/JUKI
NS-6060350-SP	NUT F/JUKI
NS-6080210-SP	NUT F/JUKI
NS-6080340-SP	NUT F/JUKI
NS-6090310-SC	NUT F/JUKI
NS-6090310-SP	NUT F/JUKI
NS-6090530-SP	NUT F/JUKI
NS-6110310-SP	NUT F/JUKI
NS-6110360-SP	NUT F/JUKI
NS-6110420-SP	NUT F/JUKI
NS-6110530-SP	NUT F/JUKI
NS-6120310-SP	NUT F/JUKI
NS-6150310-SP	NUT F/JUKI
NS-6150320-SP	NUT F/JUKI

PART NUMBER	DESCRIPTION
NS-6150430-SP	NUT F/JUKI
NS-6150430-SR	NUT F/JUKI
NS-6150440-SP	NUT F/JUKI
NS-6160520-SP	NUT F/JUKI
NS-6160520-TP	NUT F/JUKI
NS-6620310-SN	NUT F/JUKI
NS-6620310-SP	LOCK NUT F/JUKI
NS-6660340-SP	NUT F/JUKI
NS-6660430-SP	NUT F/JUKI
NS-6660511-SP	NUT F/JUKI
NS-6660511-TP	NUT F/JUKI
NS-6680320-SP	9/32-28 NUT F/JUKI
NS-6680410-SN	NUT F/JUKI
NS-6680410-SP	NUT F/JUKI
PF603032	PR FOOT F/KINGTEX
PF603052	PR FOOT F/KINGTEX
PF604A32	PRSR FOOT F/KINGTEX
PF604B33	PRSR FOOT F/KINGTEX
PF605A32E	PR FOOT ARM SPRING
PF605D53	FOOT F/KINGTEX
PF606CA3	PRESSER FOOT F/KINGT
PS-0150082-KH	ROLL PIN F/JUKI
PS-0200062-KH	SPRING PIN F/JUKI
PS-0200122-K0	SPRING PIN F/JUKI
PS-0250162-KH	SPRING PIN F/JUKI
PS-0300132-KH	SPRING PIN F/JUKI
PW040706	WASHER FOR KINGTEX
R0-2943101-00	RUBBER RING F/JUKI
R0-4453001-00	JUKI RUBBER RING
R-4200-E0C-C00	PLATE F/JUKI
R-4200-EOD-C00	NEEDLE PLATE F/JUKI
R-4200-EOD-D00	THROAT PLATE F/JUKI
R-4200-H0A-C00	PLATE F/JUKI
R-4200-HOD-D00	THROAT PLATE F/JUKI
R-4200-HOD-DA0	THROAT PLATE F/JUKI
R-4205-HOD-E00	THROAT PLATE F/JUKI
R-4300-E0D-E00	NEEDLE PLATE F/JUKI
R-4300-H0H-E00	JUKI NEEDLE PLATE
R-4300-H2D-E00	BACKTACK PLATE F/JUK
R-4300-HOD-D0A	THROAT PLATE F/JUKI
R-4300-HOD-E00	THROAT PLATE F/JUKI
R-4300-HOF-E00	PLATE F/JUKI
R-4305-HOD-E00	THROAT PLATE F/JUKI
R-4305-HOD-E0A	THROAT PLATE F/JUKI
R-4305-HOF-E00	PLATE F/JUKI
R-4305-HOF-E0A	PLATE F/JUKI
R-4305-J0E-E00	THROAT PLATE F/JUKI
R-4305-J0E-EA0	PLATE F/JUKI
R-4306-HOF-E00	PLATE F/JUKI
R-4308-EOD-E00	NEEDLE PLATE F/JUKI
R-4308-HOD-E00	THROAT PLATE F/JUKI

PART NUMBER	DESCRIPTION
R-4308-HOD-E0A	PLATE F/JUKI
R-4308-HOF-E00	THROAT PLATE F/JUKI
R-4308-HOF-E0A	THROAT PLATE F/JUKI
R-4508-EOD-C00	NEEDLE PLATE F/JUKI
R-4508-HOD-D00	THR PLATE F/JUKI2500
R-4508-HOD-DA0	PLATE F/JUKI
R-4608-E0D-F00	PLATE F/JUKI
R-4608-E0F-G00	PLATE F/JUKI
R-4608-E0F-G00A	PLATE F/JUKI
R-4608-HOD-F00	THROAT PLATE F/JUKI
R-4612-E0F-G00A	PLATE F/JUKI
R-4612-GOF-JA0	PLATE F/JUKI
R-4612-H0D-E01	THROAT PLATE F/JUKI
R-4612-HOD-E0I	PLATE F/JUKI
R-4612-HOF-B00	THROAT PLATE F/JUKI
R-4612-HOF-G00	THROAT PLATE F/JUKI
R-4612-J0F-F00	THROAT PLATE F/JUKI
R-4612-J0F-G00	PLATE F/JUKI
R-5300-F0H-1AD	3-NDL 1/4" FOOT F/JU
RC-0070001-KP	RETAIN RING F/JUKI
RC-0470611-KP	RING F/JUKI
RC-0650811-KP	RETAIN RING F/JUKI
RC-0658011-KP	RETAIN RING F/JUKI
RC-1021011-KP	RETAIN RING F/JUKI
RC-1381001-KP	RETAINER F/JUKI
RE-0200000-K0	SNAP RING F/JUKI
RE-0250000-K0	SNAP RING F/JUKI
RE-0300000-K0	WASHER F/JUKI
RE-0320000-K0	E-RING F/JUKI
RE-0400000-K0	SNAP RING F/JUKI
RE-0500000-K0	SNAP RING F/JUKI
RE-0500000-KE	SNAP RING F/JUKI
RE-0600000-K0	SNAP RING F/JUKI
RE-0800000-KO	SNAP RING F/JUKI
RE-1200000-K0	SNAP RING F/JUKI
RO-0371801-00	RUBBER RING F/JUKI
RO-0742401-00	RUBBER RING F/JUKI
RO-0982401-00	RUBBER RING F/JUKI
RO-1082401-00	RUBBER RING F/JUKI
RO-1100901-00	RUBBER RING F/JUKI
RO-2943101-00	RUBBER RING F/JUKI
RO-4453001-00	RUBBER RING F/JUKI
RO-4801201-00	RUBBER RING F/JUKI
S057-2516F	COMPL SHIR ATT F/FF6
S057-2516-FF6	SHIRRING ATTACH F/JU
S372G	ADJ BUTTON SPACER
SB-1100003-00	BALL BEARING F/JUKI
SB-1150002-00	BEARING F/JUKI
SB-1350002-00	BEARING F/JUKI
SC32440406A	SCREW FOR KINGTEX
SD-0260271-SP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SD-0280401-SL	HINGE SCREW F/JUKI
SD-0380552-SL	SCREW F/JUKI
SD-0402001-SP	SCREW F/JUKI
SD-0402001-TP	SCREW F/JUKI
SD-0450701-TP	SCREW F/JUKI
SD-0460701-TP	SCREW F/JUKI
SD-0460702-SP	SCREW F/JUKI
SD-0460702-TP	SCREW F/JUKI
SD-0460703-TP	STUD F/JUKI
SD-0500091-TP	SCREW F/JUKI
SD-0500095-TH	SCREW F/JUKI
SD-0500803-SL	SCREW F/JUKI
SD-0500803-TP	SCREW F/JUKI
SD-0530221-SP	SCREW F/JUKI
SD-0550301-SP	SCREW F/JUKI
SD-0550801-SP	SCREW STUD F/JUKI
SD-0600095-TH	HINGE SCREW F/JUKI
SD-0600271-SP	SCREW F/JUKI
SD-0601021-SP	SCREW F/JUKI
SD-0630241-SD	SCREW F/JUKI
SD-0630271-SP	HINGE SCREW F/JUKI
SD-0630275-SP	SCREW F/JUKI
SD-0630301-SP	SCREW F/JUKI
SD-0640211-SP	SCREW F/JUKI
SD-0640241-SP	SCREW F/JUKI
SD-0640322-TP	SCREW F/JUKI
SD-0640323-TP	HINGE SCREW F/JUKI
SD-0640471-SP	SCREW F/JUKI
SD-0640481-SP	SCREW F/JUKI
SD-0640482-SP	SCREW F/JUKI
SD-0640752-TH	HINGE SCREW F/JUKI
SD-0640752-TP	SCREW
SD-0641321-TP	SCREW F/JUKI
SD-0641322-TP	SCREW F/JUKI
SD-0720193-SP	SCREW F/JUKI
SD-0720193-ST	SCREW F/JUKI
SD-0720332-SP	SCREW F/JUKI
SD-0720801-TH	HINGE SCREW F/JUKI
SD-0720803-TH	HINGE SCREW F/JUKI
SD-0790203-SP	SCREW F/JUKI
SD-0790802-SP	SCREW F/JUKI
SD-0790802-TP	SCREW F/JUKI
SD-0791331-SP	STUD F/JUKI
SD-0791501-SP	SCREW F/JUKI
SD-0800402-TP	SCREW F/JUKI
SD-1127321-SP	SCREW F/JUKI
SE32440405L	SCREW FOR KINGTEX
SE36400406L	SCREW FOR KINGTEX
SF444006071	SCREW F/KINGTEX
SF44400607C	SCREW F/KINGTEX
SH24560300C	FOOT PIN F/KINGTEX

PART NUMBER	DESCRIPTION
SJ36400606M	SCREW F/KINGTEX
SK36400807A	SCREW FOR KINGTEX
SK44400907A	SCREW FOR KINGTEX
SK60281007F	SCREW
SM-6030802-TP	SCREW F/JUKI
SM-6040552-TP	SCREW F/JUKI
SM-6040802-TP	SCREW F/JUKI
SM-6051402-TP	SCREW F/JUKI
SM-6061200-SP	SCREW F/JUKI
SM-6061202-TP	SCREW F/JUKI
SM-6061402-TP	SCREW F/JUKI
SM-8030312-TP	SCREW F/JUKI
SM-8050402-TP	SCREW F/JUKI
SM-8060602-TP	SCREW F/JUKI
SM-8060612-TP	SCREW F/JUKI
SM-8080882-TP	SCREW F/JUKI
SM-9061853-SR	SCREW F/JUKI
SN44400400A	SCREW FOR KINGTEX
SS-1060210-SP	SCREW F/JUKI
SS-1060210-TP	SCREW F/JUKI
SS-1110640-SP	SCREW F/JUKI
SS-1110640-TP	SCREW F/JUKI
SS-1110710-SP	JUKI SCREW(411111070
SS-2040210-SH	SCREW F/JUKI
SS-2060210-SP	SCREW F/JUKI
SS-2060210-TP	SCREW F/JUKI
SS-2060220-SP	SCREW F/JUKI
SS-2060310-SP	SCREW F/JUKI
SS-2060510-SL	SCREW F/JUKI
SS-2060510-SP	SCREW F/JUKI
SS-2080810-SP	SCREW F/JUKI
SS-2090510-SL	SCREW F/JUKI
SS-2090510-SP	SCREW F/JUKI
SS-2090510-TP	SCREW F/JUKI
SS-2090550-TP	SCREW F/JUKI
SS-2090710-SP	SCREW F/JUKI
SS-2090710-TP	SCREW F/JUKI
SS-2110710-SP	SCREW F/JUKI
SS-2110710-TP	SCREW F/JUKI
SS-2110820-SP	SCREW F/JUKI
SS-2110910-SK	SCREW F/JUKI
SS-2110910-SL	SCREW F/JUKI
SS-2110910-SP	SCREW F/JUKI
SS-2110910-TP	SCREW F/JUKI
SS-2110915-PH	PHILLIPS HEAD SCREW
SS-2110915-SP	SCREW F/JUKI
SS-2110915-TP	SCREW F/JUKI
SS-2110920-SP	SCREW F/JUKI
SS-2110920-TP	SCREW F/JUKI
SS-2110930-SK	SCREW F/JUKI
SS-2110930-SP	PLATE SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-2111010-TP	SCREW F/JUKI
SS-3060310-SP	SCREW F/JUKI
SS-3090520-SP	SCREW F/JUKI
SS-3090610-SP	SCREW F/JUKI
SS-3150710-SP	SCREW F/JUKI
SS-3151012-TR	SCREW F/JUKI
SS-4060310-SP	SCREW F/JUKI
SS-4060310-TP	SCREW F/JUKI
SS-4080310-SP	SCREW F/JUKI
SS-4080610-SP	SCREW F/JUKI
SS-4080620-SP	SCREW F/JUKI
SS-4080620-TP	SCREW F/JUKI
SS-4090415-SP	SCREW F/ JUKI
SS-4090610-SP	SCREW F/JUKI
SS-4090610-TP	SCREW F/JUKI
SS-4090615-SP	SCREW F/JUKI
SS-4090810-SP	SCREW F/JUKI
SS-4090815-SP	SCREW F/JUKI
SS-4090815-TP	SCREW F/JUKI
SS-4110715-SP	SCREW F/JUKI
SS-4110815-SP	SCREW F/JUKI
SS-4110815-TP	SCREW F/JUKI
SS-4110910-TP	SCREW F/JUKI
SS-4110915-SP	SCREW F/JUKI
SS-4111415-SP	SCREW F/JUKI
SS-4120615-SP	SCREW F/JUKI
SS-4120915-SP	SCREW F/JUKI
SS-4121015-SP	SCREW F/JUKI
SS-5060310-SP	SCREW F/JUKI
SS-5060310-TP	SCREW F/JUKI
SS-5060410-SL	SCREW F/JUKI
SS-5060410-SP	SCREW F/JUKI
SS-5060410-TP	SCREW F/JUKI
SS-5090610-SP	SCREW F/JUKI
SS-5110710-SP	SCREW F/JUKI
SS-5110810-SP	SCREW F/JUKI
SS-6060210-SP	SCREW F/JUKI
SS-6060310-SP	SCREW F/JUKI
SS-6060310-TP	SCREW F/JUKI
SS-6060340-SP	SCREW F/JUKI
SS-6060340-TP	SCREW F/JUKI
SS-6060410-SP	SCREW F/JUKI
SS-6060410-TP	SCREW F/JUKI
SS-6060440-SP	SCREW F/JUKI
SS-6060440-TP	LOOPER SCREW F/JUKI
SS-6060510-TP	SCREW F/JUKI
SS-6060910-TP	SCREW F/JUKI
SS-6080210-SP	JUKI SCREW
SS-6080310-SP	JUKI SCREW
SS-6080320-SP	SCREW F/JUKI
SS-6080340-SP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-6080360-SP	SCREW F/LZ-271
SS-6080410-SP	SCREW F/JUKI
SS-6080410-TP	SCREW F/JUKI
SS-6080610-TP	SCREW F/JUKI
SS-6080710-SP	SCREW F/JUKI
SS-6080720-SP	SCREW F/JUKI
SS-6081010-SP	SCREW F/JUKI
SS-6081010-TP	SCREW F/JUKI
SS-6081210-SP	SCREW F/JUKI
SS-6081810-SP	JUKI SCREW
SS-6090410-SP	SCREW F/JUKI
SS-6090410-TP	SCREW F/JUKI
SS-6090420-SP	SCREW F/JUKI
SS-6090440-SP	SCREW F/JUKI
SS-6090510-SP	SCREW F/JUKI
SS-6090510-TP	SCREW F/JUKI
SS-6090520-SP	SCREW F/JUKI
SS-6090540-SP	SCREW F/JUKI
SS-6090610-SP	SCREW F/JUKI
SS-6090612-TP	SCREW F/JUKI
SS-6090620-SP	SCREW F/JUKI
SS-6090620-TP	SCREW F/JUKI
SS-6090630-SP	SCREW F/JUKI
SS-6090630-TP	SCREW F/JUKI
SS-6090650-SP	SCREW F/JUKI
SS-6090670-SP	SCREW F/JUKI
SS-6090670-TP	SCREW F/JUKI
SS-6090810-SP	SCREW F/JUKI
SS-6090810-TP	SCREW F/JUKI
SS-6090910-SP	SCREW F/JUKI
SS-6090910-TP	SCREW F/JUKI
SS-6091210-SP	SCREW F/JUKI
SS-6091210-TP	SCREW F/JUKI
SS-6110420-TP	SCREW F/JUKI
SS-6110430-SP	SCREW F/JUKI
SS-6110430-TP	SCREW F/JUKI
SS-6110480-SP	SCREW F/JUKI
SS-6110510-SP	SCREW F/JUKI
SS-6110610-TP	SCREW F/JUKI
SS-6110640-SP	SCREW F/JUKI
SS-6110710-SP	SCREW F/JUKI
SS-6110710-TP	SCREW F/JUKI
SS-6110810-TP	SCREW F/JUKI
SS-6111010-SP	SCREW F/JUKI
SS-6111010-TP	SCREW F/JUKI
SS-6111040-SP	SCREW F/JUKI
SS-6111140-SK	SCREW F/JUKI
SS-6111140-SP	SCREW F/JUKI
SS-6111210-SP	SCREW F/JUKI
SS-6120930-SP	SCREW F/JUKI
SS-6120930-TP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-6120940-SP	SCREW F/JUKI
SS-6120940-TP	SCREW F/JUKI
SS-6121010-SP	SCREW F/JUKI
SS-6121050-SP	SCREW F/JUKI
SS-6121050-TP	SCREW F/JUKI
SS-6121210-SP	SCREW F/JUKI
SS-6121212-TP	SCREW F/JUKI
SS-6121220-SP	SCREW F/JUKI
SS-6121220-TP	SCREW F/JUKI
SS-6121240-SP	SCREW F/JUKI
SS-6121240-TP	SCREW F/JUKI
SS-6121610-SP	SCREW F/JUKI
SS-6121610-TP	SCREW F/JUKI
SS-6121860-SP	SCREW F/JUKI
SS-6151412-TP	SCREW F/JUKI
SS-6151440-SP	SCREW F/JUKI
SS-6151920-SP	SCREW F/JUKI
SS-6151920-TP	SCREW F/JUKI
SS-6152440-SP	SCREW F/JUKI
SS-6153040-SP	SCREW F/JUKI
SS-6560150-SH	SCREW F/JUKI
SS-6560250-SH	SCREW F/JUKI
SS-6580612-TP	SCREW F/JUKI
SS-6580752-SP	SCREW F/JUKI
SS-6580752-TP	SCREW F/JUKI
SS-6660710-TP	SCREW F/JUKI
SS-6661110-SK	SCREW F/JUKI
SS-6661110-SP	SCREW F/JUKI
SS-6741512-TP	SCREW F/JUKI
SS-6742012-TP	SCREW F/JUKI
SS-7060310-SP	SCREW F/JUKI
SS-7060510-SD	SCREW F/JUKI
SS-7060510-SP	SCREW F/JUKI
SS-7060510-TP	SCREW F/JUKI
SS-7060610-SP	SCREW F/JUKI
SS-7060610-TP	SCREW F/JUKI
SS-7080310-SK	SCREW F/JUKI
SS-7080310-SP	SCREW F/JUKI
SS-7080410-SP	SCREW F/JUKI
SS-7080510-SK	SCREW F/JUKI
SS-7080510-SP	SCREW F/JUKI
SS-7080510-TP	SCREW F/JUKI
SS-7080520-SP	SCREW F/JUKI
SS-7090110-SK	SCREW F/JUKI
SS-7090110-SP	SCREW F/JUKI
SS-7090110-TP	SCREW F/JUKI
SS-7090410-SP	SCREW F/JUKI
SS-7090410-TP	SCREW F/JUKI
SS-7090510-SL	SCREW F/JUKI
SS-7090510-SP	SCREW F/JUKI
SS-7090520-SL	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-7090520-SP	SCREW F/JUKI
SS-7090520-TP	SCREW F/JUKI
SS-7090530-SP	SCREW F/JUKI
SS-7090540-SP	SCREW F/JUKI
SS-7090540-TP	SCREW F/JUKI
SS-7090610-SP	SCREW F/JUKI
SS-7090620-TP	SCREW F/JUKI
SS-7090670-SP	SCREW F/JUKI
SS-7090710-SL	SCREW F/JUKI
SS-7090710-SP	SCREW F/JUKI
SS-7090910-SP	SCREW F/JUKI
SS-7090910-TP	SCREW F/JUKI
SS-7091110-SP	SCREW F/JUKI
SS-7091110-TP	SCREW F/JUKI
SS-7110340-SP	SCREW F/JUKI
SS-7110410-SN	SCREW F/JUKI
SS-7110410-SP	SCREW F/JUKI
SS-7110410-TP	SCREW F/JUKI
SS-7110510-SP	SCREW F/JUKI
SS-7110510-TP	SCREW F/JUKI
SS-7110540-SP	SCREW F/JUKI
SS-7110710-SL	SCREW F/JUKI
SS-7110710-SP	SCREW F/JUKI
SS-7110710-TP	SCREWS F/JUKI
SS-7110720-SP	SCREW F/JUKI
SS-7110720-TP	SCREW F/JUKI
SS-7110740-SP	SCREW F/JUKI
SS-7110740-TP	SCREW F/JUKI
SS-7110810-SP	SCREW F/JUKI
SS-7110820-SP	SCREW F/JUKI
SS-7110840-SP	SCREW F/JUKI
SS-7110840-TP	SCREW F/JUKI
SS-7110910-SP	SCREW F/JUKI
SS-7110910-TP	SCREW F/JUKI
SS-7111110-SK	SCREW F/JUKI
SS-7111110-SP	SCREW F/JUKI
SS-7111120-SP	SCREW F/JUKI
SS-7111310-SP	SCREW F/JUKI
SS-7111310-TP	SCREW F/JUKI
SS-7111410-SP	SCREW F/JUKI
SS-7111410-TP	SCREW F/JUKI
SS-7112420-SP	SCREW F/JUKI
SS-7112420-TP	SCREW F/JUKI
SS-7120640-SP	SCREW F/JUKI
SS-7120910-SP	SCREW F/JUKI
SS-7120910-TP	SCREW F/JUKI
SS-7121410-SP	SCREW F/JUKI
SS-7121410-TP	SCREW F/JUKI
SS-7150940-SP	SCREW F/JUKI
SS-7151120-SP	SCREW F/JUKI
SS-7151210-SP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-7151330-SP	SCREW F/JUKI
SS-7161640-SP	SCREW F/JUKI
SS-7620750-SP	SCREW F/JUKI
SS-7621040-SP	SCREW F/JUKI
SS-7661110-TH	SCREW F/JUKI
SS-7681650-SP	SCREW F/JUKI
SS-7681650-TP	SCREW F/JUKI
SS-7681750-SP	SCREW F/JUKI
SS-7681750-TP	SCREW F/JUKI
SS-7701010-SP	SCREW F/JUKI
SS-8050502-TP	SCREW F/JUKI
SS-8080310-SP	SCREW F/JUKI
SS-8080310-TP	SCREW F/JUKI
SS-8080322-SP	SCREW F/JUKI
SS-8080322-TP	SCREW F/JUKI
SS-8080410-SP	SCREW F/JUKI
SS-8080410-SP-AH	ALLEN HEAD SCREW
SS-8080410-TP	SCREW F/JUKI
SS-8080410-TP-AH	ALLEN HEAD SCREW
SS-8080610-SP	SCREW F/JUKI
SS-8080610-TP	SCREW F/JUKI
SS-8080660-TP	SCREW F/JUKI
SS-8081050-TH	SCREW F/JUKI
SS-8090410-SP	SCREW F/JUKI
SS-8090410-TP	SCREW F/JUKI
SS-8090530-TP	SCREW F/JUKI
SS-8090540-SP	SCREW F/JUKI
SS-8090610-SP	SCREW F/JUKI
SS-8090670-SP	SCREW F/JUKI
SS-8090710-SP	SCREW F/JUKI
SS-8110410-SP	SCREW F/JUKI
SS-8110410-TP	SCREW F/JUKI
SS-8110422-SP	SCREW F/JUKI
SS-8110422-TP	SCREW F/JUKI
SS-8110510-SP	SCREW F/JUKI
SS-8110520-SP	SCREW F/JUKI
SS-8110710-SP	SCREW F/JUKI
SS-8110750-SP	SCREW F/JUKI
SS-8111251-SP	SCREW F/JUKI
SS-8111610-SP	SCREW F/JUKI
SS-8120740-SP	SCREW F/JUKI
SS-8150310-SP	SCREW F/JUKI
SS-8150410-SP	SCREW F/JUKI
SS-8150410-TP	SCREW F/JUKI
SS-8150510-SP	SCREW F/JUKI
SS-8150510-TP	SCREW F/JUKI
SS-8150710-SN	SCREW F/JUKI
SS-8150710-SP	SCREW F/JUKI
SS-8150710-TP	SCREW F/JUKI
SS-8150822-TP	SCREW F/JUKI
SS-8150840-SP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-8151150-SK	SCREW F/JUKI
SS-8151150-SN	SCREW F/JUKI
SS-8151150-SP	SCREW F/JUKI
SS-8151150-TP	SCREW F/JUKI
SS-8151160-SP	SCREW F/JUKI
SS-8151230-SP	SCREW F/JUKI
SS-8151280-SP	SCREW F/JUKI
SS-8151550-SP	SCREW F/JUKI
SS-8151570-SP	SCREW F/JUKI
SS-8151770-SK	SCREW F/JUKI
SS-8151770-SP	SCREW F/JUKI
SS-8151780-SP	SCREW F/JUKI
SS-8152030-SP	SCREW F/JUKI
SS-8152080-SP	SCREW F/JUKI
SS-8152080-SR	SCREW F/JUKI
SS-8620610-TP	SCREW F/JUKI
SS-8660530-TP	SCREW F/JUKI
SS-8660610-TP	SCREW F/JUKI
SS-8660612-TP	SCREW F/JUKI
SS-8660670-SP	SET SCREW(BALL POINT
SS-8660770-SP	SCREW F/JUKI
SS-8660810-TP	SCREW F/JUKI
SS-8660820-SP	SCREW F/JUKI
SS-8660830-TP	SCREW F/JUKI
SS-8660970-SK	SCREW F/JUKI
SS-8660970-SP	SCREW F/JUKI
SS-8660970-TP	SCREW F/JUKI
SS-8661112-TP	SCREW F/JUKI
SS-8680540-SK	SCREW F/JUKI
SS-8680540-SP	SCREW F/JUKI
SS-8680810-TP	SCREW F/JUKI
SS-8681412-TP	SET SCREW F/JUKI
SS-8681650-SP	SCREW F/JUKI
SS-8681650-TP	SCREW F/JUKI
SS-8701042-TP	SCREW F/JUKI
SS-8701782-TP	SCREW F/JUKI
SS-9080410-SP	SCREW F/JUKI
SS-9090410-SP	SCREW F/JUKI
SS-9090410-TP	SCREW F/JUKI
SS-9090610-SP	SCREW F/JUKI
SS-9090610-TP	SCREW F/JUKI
SS-9090640-SP	SCREW F/JUKI
SS-9090813-SP	SCREW F/JUKI
SS-9090813-TP	SCREW F/JUKI
SS-9091810-SP	SCREW F/JUKI
SS-9110430-TP	UP LPR SET SCREW F/J
SS-9111010-SK	SCREW F/JUKI
SS-9111010-SP	SCREW F/JUKI
SS-9111010-SR	SCREW F/JUKI
SS-9111010-TP	SCREW F/JUKI
SS-9111013-SP	SCREW F/JUKI

PART NUMBER	DESCRIPTION
SS-9111050-SP	SCREW F/JUKI
SS-9111610-SP	SCREW F/JUKI
SS-9111610-TP	SCREW F/JUKI
SS-9111810-SP	SCREW F/JUKI
SS-9111820-SP	SCREW F/JUKI
SS-9112310-SP	SCREW F/JUKI
SS-9112310-TP	SCREW F/JUKI
SS-9112510-SP	SCREW F/JUKI
SS-9120643-TP	SCREW F/JUKI
SS-9120910-TP	SCREW F/JUKI
SS-9121340-CP	SCREW F/JUKI
SS-9150710-TP	SCREW F/JUKI
SS-9150860-SP	SCREW F/JUKI
SS-9151120-CP	SCREW F/JUKI
SS-9151120-SK	SCREW F/JUKI
SS-9151120-SP	SCREW F/JUKI
SS-9151160-CP	SCREW F/JUKI
SS-9151160-SP	SCREW F/JUKI
SS-9151210-TP	SCREW F/JUKI
SS-9151220-SP	SCREW F/JUKI
SS-9151220-SR	SCREW F/JUKI
SS-9151420-TP	SCREW F/JUKI
SS-9151440-CP	SCREW F/JUKI
SS-9151440-SP	SCREW F/JUKI
SS-9151440-TP	SCREW F/JUKI
SS-9151610-SP	SCREW F/JUKI
SS-9151610-SR	SCREW F/JUKI
SS-9152130-CP	SCREW F/JUKI
SS-9152130-SK	SCREW F/JUKI
SS-9152130-SP	SCREW F/JUKI
SS-9161610-SP	SCREW F/JUKI
SS-9182010-SN	SCREW F/JUKI
SS-9201813-CN	SCREW F/JUKI
SS-9201813-CP	SCREW F/SCREW
SS-9201813-SP	SCREW F/JUKI
SS-9202443-CP	SCREW F/JUKI
SS-9621413-SP	SCREW F/JUKI
SS-9661120-CP	SCREW F/JUKI
SS-9661230-CP	SCREW F/JUKI
SS-9681610-TP	SCREW F/JUKI
T022	FLAT CHN CUTTER F/JU
T035	FLAT CHN CUTTER F/JU
T041	FLAT CHN CUTTER F/JU
T042	SIDE CHN CUTTER F/JU
TA-0800704-R0	RUBBER PLUG F/JUKI
TA-1250406-R0	RUBBER PLUG F/JUKI
TA-1250406-RO	RUBBER PLUG F/JUKI
TA-2351004-R0	RUBBER PLUG F/JUKI
TP603032	THRT PLATE F/KINGTEX
TP603053	THRT PLATE F/KINGTEX
TP604A32	THRT PLATE F/KINGTEX

PART NUMBER	DESCRIPTION
TP604A33	THROAT PLATE F/KINGT
TP604A42	NEEDLE PLATE
TP604A43	THRT PLATE F/KINGTEX
TP604A53	PLATE F/KINGTEX
TP604B53	THRT PLATE F/KINGTEX
TP605C33	THRT PLATE F/KINGTEX
TP605C53	THRT PLATE F/KINGTEX
TP605D53	THRT PLATE F/KINGTEX
TP606CA3	THRT PLATE F/KINGTEX
U-93A-VAL	HOOK F/NAKAJIMA 580L
UL600880	LOOPER F/KINGTEX
UL600881	LOOPER F/KINGTEX
UL603880	UPPER LOOPER F/KING
UL603881	UPPER LOOPER F/KINGT
UL604883	UPPER LOOPER
W-1528-804-000	CHAIN CUTTER F/JUKI
WP-0250516-SD	WASHER F/JUKI
WP-0330500-0E	WASHER F/JUKI
WP-0330500-MB	WASHER F/JUKI
WP-0330500-SB	WASHER F/JUKI
WP-0370316-SD	WASHER F/JUKI
WP-0370616-SD	NUT F/JUKI
WP-0371016-SA	WASHER F/JUKI
WP-0371016-SD	WASHER F/JUKI
WP-0371016-SP	WASHER F/JUKI
WP-0371026-SD	WASHER F/JUKI
WP-0450801-SD	WASHER F/JUKI
WP-0450801-SP	WASHER F/JUKI
WP-0450846-SP	WASHER F/JUKI
WP-0451016-SD	WASHER F/JUKI
WP-0451040-KP	WASHER F/JUKI
WP-0480856-SD	WASHER F/JUKI
WP-0480856-SP	WASHER F/JUKI
WP-0482086-SD	WASHER F/JUKI
WP-0482086-SP	WASHER F/JUKI
WP-0501016-SC	WASHER F/JUKI
WP-0501016-SD	WASHER F/JUKI
WP-0501016-SP	WASHER F/JUKI
WP-0560860-SE	WASHER F/JUKI
WP-0612056-SD	WASHER F/JUKI
WP-0612056-SP	WASHER F/JUKI
WP-0621016-SC	WASHER F/JUKI
WP-0621016-SP	WASHER F/JUKI
WP-0621026-SP	WASHER F/JUKI
WP-0650876-SD	WASHER F/JUKI
WP-0651001-SB	WASHER F/JUKI
WP-0651056-SD	WASHER F/JUKI
WP-0651056-SH	WASHER F/JUKI
WP-0651056-SP	WASHER F/JUKI
WP-0703516-SP	WASHER F/JUKI
WP-0704016-SP	WASHER F/JUKI

PART NUMBER	DESCRIPTION
WP-0740516-SP	WASHER F/JUKI
WP-0751576-SD	WASHER F/JUKI
WS-0441010-KP	WASHER F/JUKI
WS-0441040-KP	WASHER F/JUKI
WS-0451040-KP	WASHER F/JUKI
WS-0521010-KN	LOCK WASHER F/JUKI
WS-0641560-KR	SPRING WASHER F/JUKI
WS-0650389-KP	WASHER F/JUKI
WS-0651510-KP	WASHER F/JUKI
WS-0822010-KP	LOCK WASHER F/JUKI
WZ-0430200-KH	WASHER F/JUKI
WZ-0641510-KP	WASHER F/JUKI
WZ-0850302-K0	WAVE WASHER F/JUKI